

NR3700-O/G

10MHz Frequency Reference, OCXO, GPS/GNSS Locked Single Channel, Auto-Cal



All information provided herein is the proprietary property of Novus Power Products L.L.C. The information included may be reproduced without the permission or prior approval of Novus Power Products L.L.C. for the purpose of operating the Novus equipment.

Table of Contents

1.0 Overview	3
2.0 Crystal	5
3.0 GPS Receiver	11
4.0 Input/Output Connectors/Mechanical	12
5.0 Typical Phase Noise	14
6.0 Alerts - Optional Function Relay	14
7.0 GPS/GNSS Function	14
8.0 Technical Specification	17
8.1 Performance	17
8.2 Environmental and Mechanical	17
9.0 LIMITED HARDWARE WARRANTY	18
10.0 Appendix A – NMEA, Radio Control and Status	19

1.0 Overview

The NR3700-O/G is a GPS locked OCXO 10 MHz frequency reference with optional PPS and RS232. The unit features Auto-Calibration such that the most recent coefficients to compensate the OCXO for drift due to aging and/or temperature are stored and applied to the OCXO during GPS loss of lock conditions. These coefficients are updated after 8 hours of continuous GPS locked state. This effectively eliminates long-term OCXO changes.

Options: RS232, TCXO, and Ultra Low Phase Noise OCXO

The RS 232 interface provides access to the NMEA-0183 data from the GPS at a baud rate of 38.4K. The baud rate can be changed through the RS232 port using commands described in Appendix A (Output Format Section).

The unit operates from power in the voltage range of -60 to +60 Vdc in three power supply ranges that must be specified at purchase. There is also an AC power adapter available.

The output is a 10 MHz sinewave at 4.5 dBm (0.38 Vrms). The output is short circuit and transient protected.

PPS pulse is a LVCMOS signal and is also short and transient protected. The PPS has an accuracy of 30 ns rms.

The Global Positioning System (GPS) transmits a wealth of data. The information is routinely used for position and timing. This signal is what is used by all GPS disciplined oscillators for master timing.

The first part of the process is acquiring the GPS satellites and deriving what is called the PPS signal. This is a pulse that occurs once a second. Most GPS receivers will specify an accuracy for the leading edge in the range of ~20 ns rms. Due to atmospheric conditions, multi-path and other effects, there is considerable jitter on the pulse. This pulse, with exceptional long-term accuracy of ~E-12, is the starting point for the GPSDO.

The PPS is used to derive a 10MHz signal. As you can imagine, the algorithms for the generation of the 10MHz are very sophisticated. You are, in effect, creating a 10MHz waveform with frequency measured once a second by a waveform which has considerable jitter.

To get a useful frequency reference, the jitter (phase noise) of the frequency reference must be improved. A very low bandwidth phase locked loop is used to lock a high performance 10 MHz OCXO to the synthesized disciplined 10 MHz. By virtue of having a very low bandwidth, the high frequency jitter is dramatically reduced. There are numerous tradeoffs - speed of acquisition, phase error, stability, cost, etc. It is a complex feedback loop and as such, there are many solutions. Noise on the final output is also affected by the noise in the system. Noise from power supplies and other circuits can easily sum with the output signal. Care has been taken throughout the design to achieve a high quality signal.

The phase noise of the output is now largely dominated by the voltage controlled oscillator. The oscillator is typically a crystal oscillator and the quality of that device can vary significantly. The NR3700-CAL uses an oven-controlled oscillator to provide an unlocked stability of under 50 ppb/year.

The calibration feature continually monitors the correction coefficients developed through GPS timing information. These are sampled multiple times per day and stored in non-volatile memory and in the event of a GPS loss, the saved coefficients are applied to the TCXO. This effectively eliminates long-term crystal drift.

The NR3700-O/G also incorporates built-in test to monitor critical parameters such as the TCXO, power supplies and other functions. The built-in test drives a front panel indicator.

The GPS lock status is also provided by a front panel indicator and a signal accessible on the front panel DB-9. Many systems will use this signal to detect a long-term GPS loss-of-lock state which may be caused by an antenna or cabling issue.


The NR3700-O/G draws less than 10 Watts of power from a 12 VDC nominal source. An AC power adapter is available as an option to allow direct operation from standard AC power. Also, Novus offers related NR3700 products that can operate anywhere from – 60 to +60 VDC. Contact the factory for further details.

2.0 Crystal

Novus crystal based frequency reference products are based upon either TCXO or OCXO technology. Temperature compensated crystal oscillators will normally use an AT cut crystal and electronically compensate the device with temperature. An OCXO device uses a SC (stress compensated) crystal and the part is held at a fixed temperature to minimize temperature drift.

The TCXO implementation results in a temperature stable reference in the single digit parts per million. An OCXO device affords a reference that is almost 2 orders of magnitude more stable than the TCXO.

Comparison of an AT versus a SC cut crystal




Over a broad temperature range, an AT performs very well and much easier to compensate electronically. It is also a simpler crystal to manufacture than a SC cut device. For applications where a stability of a few ppm is acceptable, a TCXO can be a cost effective alternative.

The SC cut results in a much higher Q device and achieves much lower phase noise than the AT cut. Due to the SC cut being sensitive to pressure and temperature variation, it is mounted in a temperature controlled hermetic chamber.

OCXO oven temperature is in the range of 90°C. The device heats up and becomes stable within ~ 5 minutes.

OCXO Frequency Error from cold start




Typical OCXO



Another alternative for a frequency reference is an atomic reference. These devices use a change in atomic state of an isotope of Cesium or Rubidium for stability. Instead of a stability of ± 50 ppb/year for a typical OCXO - stability of ± 1 ppb/year is very common.


Atomic sources are very complex and while a very stable source, phase noise performance may not be acceptable for many applications.

Typical phase noise performance for a Rubidium source



For applications requiring the stability of an atomic source but also requiring low phase noise, a low phase noise OCXO is disciplined to an atomic source. The phase noise for the NR2310-R/O has phase noise improved by well over 20 dB by this technique.

Typical Phase Noise Performance-Rubidium with OCXO




When the stability of an atomic or crystal source is not sufficient, a GNSS disciplined source is an option. A GNSS receiver is installed and timing information from the GNSS


is used to discipline the timing device. Timing accuracy to a few ppb is readily achievable.



The GNSS is used to provide timing for a DDS (direct digital waveform synthesizer). While the DDS has outstanding long-term accuracy, the short-term stability is very poor due to the nature of the timing source. A GNSS timing source has considerable short-term instability due to the numerous radio effects-multi-path, signal weakness etc. In order to develop a stable reference, the GNSS timing waveform is used to discipline a low noise source with a Kalman filter. A good example of the improved jitter performance of a Kalman filter is shown below:

Kalman Filter Performance



Typical acceptance testing data for the NR3620-CAL GNSS Locked Reference

				Novus- Reference Group			
				201 N Forest Ave Suite 225			
				Independence, MO 64050			
				866 984 6887			
Date	1/12/2015	Model	NR3620-CAL				
Tech	DS	Serial	03150565	Actual			
Output amplitude				Frequency Locked		Frequency Unlocked	
				Count (second)	Frequency	Actual - Deviation (ppb)	Frequency Unlocked
Hi Limit	1.25			1	9999999.998	-0.174	9999999.995
Measurement Hi	1.00			2	9999999.998	-0.198	9999999.994
Measurement Low	0.99			3	9999999.998	-0.198	9999999.995
Low limit	0.8			4	9999999.998	-0.176	9999999.995
				5	9999999.998	-0.163	9999999.994
				6	9999999.998	-0.173	9999999.995
				7	9999999.998	-0.176	9999999.994
				8	9999999.998	-0.223	9999999.995
Frequency Specification		Limit ±15ppb		9	9999999.998	-0.230	9999999.994
				10	9999999.998	-0.193	9999999.994
Equipment	Model	Cal Exp Date		11	9999999.998	-0.212	9999999.995
Frequency Counter	Agilent 53230a	9/8/2015		12	9999999.998	-0.217	9999999.995
				13	9999999.998	-0.220	9999999.995
				14	9999999.998	-0.200	9999999.995
				15	9999999.998	-0.177	9999999.994
				16	9999999.998	-0.226	9999999.994
				17	9999999.998	-0.178	9999999.995
				18	9999999.998	-0.223	9999999.994
				19	9999999.998	-0.225	9999999.995
				20	9999999.998	-0.206	9999999.994
				21	9999999.998	-0.245	9999999.995
				22	9999999.998	-0.184	9999999.995
				23	9999999.998	-0.213	9999999.995
				24	9999999.998	-0.223	9999999.994
				25	9999999.997	-0.255	9999999.995
				26	9999999.998	-0.232	9999999.995
				27	9999999.998	-0.238	9999999.994
				28	9999999.997	-0.277	9999999.994
				29	9999999.997	-0.254	9999999.995
				30	9999999.998	-0.219	9999999.994



3.0 GPS Receiver


The receiver and companion elements generate the GNSS sine wave, PPS and NMEA serial link. The serial link conforms to NMEA 0183 protocol. The 26 channel high-sensitivity, high-accuracy Multi-GNSS receiver. Supports TRAIM, GPS, GLONASS, QZSS, SBAS, Active Anti-Jamming and Advanced Multipath Mitigation Functions.

Typical Antenna Specs:

Frequency Band	1574 – 1607 MHz
Antenna Gain	2 dBic @ 90°
Amplifier Gain	@ 3.0Vdc: 26dB (typ)
Polarization	RHCP
Out-of-band Rejection	>60dBc @ $f_0 \pm 50\text{MHz}$
Impedance	50 Ω
VSWR	2.0 Max
DC Input	2.8V - 6V
Noise Figure	<2.0dB
Power Consumption	25mA (typ)

4.0 Input/Output Connectors/Mechanical

All versions of the NR3700 are available in a flanged chassis.



GPS Ant - SMA connects to the GPS ant - provides 3.3 VDC 45ma max

PPS – SMA - one pulse per second (Optional)

10MHz sine – BNC - sine or CMOS output

RS232 - standard NMEA output NMEA-0183

Power - 2 pin Euro / Phoenix type (DigikeyED10546-ND)



The DB-9 contains the NMEA serial lines at standard RS232 levels.

Pin

- | | |
|---|------------------------------|
| 1 | N/C |
| 2 | NMEA - Tx |
| 3 | NMEA- Rx |
| 4 | Factory Pin (do not connect) |
| 5 | GND |
| 6 | N/C |
| 7 | N/C |
| 8 | N/C |
| 9 | N/C |

5.0 Typical Phase Noise

10MHz Sine- Primary Output

Offset Frequency (Hz)	Typical (dBc / Hz)
10	-95
100	-115
1K	-140
10K	-145





There are optional phase noise performance levels available - contact factory.

6.0 Alerts - Optional Function Relay

There are a number of critical circuits in the unit. These are monitored and a failure of any of these will initiate an ALERT condition. The ALERT LED green to red and the (optional) ALERT relay will open. The normal operating state is the relay contacts will be closed. During cold start, the oven can behave in such a manner as to give an Oven alert. This is normal and will only occur from a cold start. This condition should only exist for approximately five minutes.

Units manufactured after June 1, 2016 move combines the GNSS lock and alert relay to a single series connection that is routed to the rear connector. When the unit passes self-test and achieves GNSS lock, the relay closes.

Front Panel LED

GPS Locked / TCXO Loop Locked	
GPS Locked / TCXO Loop Unlocked	
GPS Tracking / Pending Lock	
Alert Status	

7.0 GPS/GNSS Function

The receiver needs to be able to see at least four satellite vehicles (SVs) to obtain an accurate 3-D position fix. When travelling in a valley, or built-up area, or under heavy tree cover, you will experience difficulty acquiring and maintaining a coherent satellite lock. Complete satellite lock may be lost, or only enough satellites (3) tracked to be able to compute a 2-D position fix, or a poor 3D fix due to insufficient satellite geometry (i.e. poor DOP). Inside a building or beneath a bridge, it may not be possible to update a position fix. The receiver can operate in 2-D mode if it goes down to seeing only three satellites by assuming its height remains constant. But this assumption can lead to very large errors, especially when a change in height does occur. A 2-D position fix is not considered a good or accurate fix; it is simply “better than nothing”.

The receiver’s antenna must have a clear view of the sky to acquire satellite lock. Remember, it is the location of the antenna that will be given as the position fix. If the antenna is mounted on a vehicle, survey pole, or backpack, allowance for this must be made when using the solution.

To measure the range from the satellite to the receiver, two criteria are required: signal transmission time and signal reception time. All GPS satellites have several atomic clocks that keep precise time and are used to time-tag the message (i.e. code the transmission time onto the signal) and to control the transmission sequence of the coded signal. The receiver has an internal clock to precisely identify the arrival time of the signal. Transit speed of the signal is a known constant (the speed of light), therefore: $\text{time} \times \text{speed of light} = \text{distance}$.

Once the receiver calculates the range to a satellite, it knows that it lies somewhere on an imaginary sphere whose radius is equal to this range. If a second satellite is then found, a second sphere can again be calculated from this range information. The receiver will now know that it lies somewhere on the circle of points produced where these two spheres intersect.

When a third satellite is detected and a range determined, a third sphere intersects the area formed by the other two. This intersection occurs at just two points. A fourth satellite is then used to synchronize the receiver clock to the satellite clocks.

In practice, just four satellite measurements are sufficient for the receiver to determine a position, as one of the two points will be totally unreasonable (possibly many kilometers out into space). This assumes the satellite and receiver timing to be identical. In reality, when the receiver compares the incoming signal with its own internal copy of the code and clock, the two will no longer be synchronized. Timing error in the satellite clocks, the receiver and other anomalies mean that the measurement of the signal transit time is in error. This, effectively, is a constant for all satellites since each measurement is made simultaneously on parallel tracking channels. Because of this, the resulting ranges calculated are known as “pseudo-ranges”.

To overcome these errors, the receiver then matches or “skews” its own code to become synchronous with the satellite signal. This is repeated for all satellites in turn, thus measuring the relative transit times of individual signals. By accurately knowing all satellite positions, and measuring the signal transit times, the user’s position can be accurately determined.

The GPS Lock LED illuminates green when the unit is locked to the GPS system. If the LED is red, the unit is operating on the TCXO.

The GPS lock status is on the RS232 connector. After June 1, 2016 the GNSS lock and status relay is combined and available on the rear panel connector pins 3,4.

If the GPS indicator remains red for an extended period of time, it could be an indication of an antenna, cabling or unit malfunction. Confirm the antenna is still connected and has not become obstructed from a clear view of the sky. To check the unit, an alternate antenna can be tried in order to isolate the malfunction. For further support, please contact the factory 866-313-9401

8.0 Technical Specification

8.1 Performance

10MHz Sine	5 +-1 dBm, 50 Ohm - BNC
Harmonics	Less than -30 dBc
Locked Stability	<~E-11 after 100 seconds
RS232 (optional)	NMEA 0183 at full RS232 Levels, default is 38.4K Baud
First Year Frequency Stability	±50 ppb (long-term unlocked)
Temp Stability	±10 ppb
Receiver Sensitivity	-155dBm
PPS (Optional)	30ns RMS accuracy, 3.3 volt logic, output impedance CMOS (±20ma)
Power Requirements	9 to 15 VDC @ 1.0 amps max (10 Watts)
Connectors	BNC - 10 MHz output
	SMA - PPS 3.3 VDC CMOS (optional)
	2 pin Euro / Phoenix type (DigikeyED10546-ND)

8.2 Environmental and Mechanical

Operating Temperature	0 to 50°C non-condensing (extended temperature range available)
Storage Temperature	-40 to 70°C
Width	3.5" (exclusive of connectors)
Depth	4.0"
Height	1.5"
Weight	~16 oz.

9.0 LIMITED HARDWARE WARRANTY

Novus Power Products (hereinafter Novus) warrants its products to the original end user ("original purchaser") and warranty is not transferrable. Novus guarantees that the NOVUS hardware products that you have purchased from NOVUS are free from defects in materials or workmanship under normal use during the LIMITED WARRANTY PERIOD. The LIMITED WARRANTY PERIOD starts on the date of shipment and for the period of 1 (one) year to be free from defects caused by faulty materials or poor workmanship, provided:

- (a) NOVUS is notified in writing by Buyer of such defect prior to the expiration of the warranty period, and
- (b) after receiving return authorization –RMA- from NOVUS, the defective item is returned with transportation prepaid to NOVUS, Independence, Missouri, with transportation charges prepaid by Buyer ...see RMA policy in Terms and conditions, and
- (c) NOVUS's examination of such unit shall disclose to its satisfaction that such defect(s) exist and have not been caused by misuse, neglect, improper installation, improper storage, unauthorized modifications, inadequate maintenance, operation outside the environmental specifications for the product, repair alteration, or accident. NOVUS assumes no risk or liability for results of the use of products purchased from it, including but without limiting the generality of the foregoing: (1) the use in combination with any electrical or electronic components, circuits, systems, assemblies or any other materials or substances; (2) unsuitability of any product for use in any circuit or assembly. Removal or tampering with tamper-proof label on merchandise will void warranty coverage unless with the written authorization from NOVUS
- (d) an evaluation fee will be charged to Buyer to cover inspection and testing costs for any item returned by Buyer under this paragraph which is found to be within specifications and/or otherwise not the responsibility of NOVUS under the terms and conditions of this paragraph or any other part of this Agreement..

Your dated sales or delivery receipt is your proof of the purchase date. You may be required to provide proof of purchase as a condition of receiving warranty service. You are entitled to hardware warranty service according to the terms and conditions of this document if a repair to your NOVUS product is required during the limited warranty period. Our obligation at NOVUS is limited to repair or replace products which prove to be defective.

Should Novus be unable to repair or replace the product within a reasonable amount of time, the customer's alternate remedy shall be a refund of the purchase price upon return of the product to Novus. The liability of NOVUS under this warranty is limited to replacing, repairing or issuing a credit, at its option, for any such item returned by Buyer under the terms of this warranty.

EXCLUSIONS: The above warranty shall not apply to defects resulting from improper or inadequate maintenance by the customer, customer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product or improper site preparation and maintenance (if applicable). For probes, cables, antennas and accessories, the warranty period is 90 (ninety) days.

PRODUCT SPECIFICATIONS: Published specifications whether contained herein or in any other materials or documents distributed to Buyer by Novus do not become final or binding on NOVUS until approved by NOVUS. NOVUS expressly reserves the right to change or modify specifications at any time without prior notice.

WARRANTY LIMITATIONS: NOVUS MAKES NO OTHER WARRANTY, EITHER EXPRESSED OR IMPLIED, WITH RESPECT TO THIS PRODUCT. NOVUS SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

IN ALL CIRCUMSTANCES NOVUS' MAXIMUM LIABILITY IS LIMITED TO THE PURCHASE PRICE OF THE PRODUCTS SOLD. NOVUS SHALL NOT, UNDER ANY CIRCUMSTANCES BE LIABLE UPON A CLAIM OR ACTION IN CONTRACT, TORT, INDEMNITY OR CONTRIBUTION OR OTHER CLAIMS RELATING TO THE PRODUCTS IT SELLS WHICH EXCEEDS THIS LIABILITY LIMIT. NOVUS SHALL NOT BE LIABLE FOR THIRD PARTY CLAIMS FOR DAMAGES AGAINST THE CUSTOMER, OR FOR MALFUNCTION, DELAYS, INTERRUPTION OF SERVICE, LOSS OF BUSINESS, LOSS OR DAMAGE TO EXEMPLARY DAMAGES, WHETHER OR NOT NOVUS HAS BEEN MADE AWARE OF THE POSSIBILITY OF SUCH CLAIMS OR DAMAGES.

LIMITATION OF REMEDIES: REGARDLESS OF WHETHER ANY REMEDY SET FORTH HEREIN FAILS OF ITS ESSENTIAL PURPOSE, IN NO EVENT WILL NOVUS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INDIRECT OR SIMILAR DAMAGES, INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF DATA OR BUSINESS INFORMATION (OR OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF OR INABILITY TO USE THE HARDWARE SUPPLIED THEREWITH EVEN IF NOVUS OR ANYONE ELSE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR FOR ANY CLAIM BY ANY OTHER PARTY. EXCLUDED DAMAGES SHALL INCLUDE, BUT ARE NOT LIMITED TO: COSTS OF REMOVAL AND INSTALLATION, LOSSES SUSTAINED AS THE RESULT OF INJURY TO ANY PERSON, OR DAMAGE TO PROPERTY.



Users manual

NR3700-O/G

Revision #:

A

Date:

9-13-16

EXCLUSIVE REMEDIES: THE REMEDIES PROVIDED HEREIN ARE THE CUSTOMERS' SOLE AND EXCLUSIVE REMEDIES. IN NO EVENT SHALL NOVUS BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY.

10.0 Appendix A – NMEA, Radio Control and Status

Users Manual**Appendix A****Appendix A****GPS/GNSS Receiver Communications Specification
NMEA-0183**

All information provided herein is the proprietary property of Novus Power Products L.L.C. The information included may be reproduced without the permission of Novus Power Products L.L.C. without prior approval for purpose of operating the equipment.

Table of Contents:

1	COMMUNICATION SPECIFICATION	4
2	SERIAL DATA OUTPUT TIMING $\Delta 4$.....	5
3	NMEA SENTENCE FORMAT	6
4	PROPRIETARY SENTENCE FORMAT:	7
5	STANDARD NMEA OUTPUT SENTENCES.....	8
	GGA – GLOBAL POSITIONING SYSTEM FIX DATA FORMAT:.....	9
	GLL – GEOGRAPHIC POSITION -LATITUDE/LONGITUDE $\Delta 6$	10
	GNS – GNSS FIX DATA FORMAT:	11
	GSA – GNSS DOP AND ACTIVE SATELLITES $\Delta 4$	12
	GSV – GNSS SATELLITES IN VIEW $\Delta 4$	13
	RMC – RECOMMENDED MINIMUM NAVIGATION INFORMATION $\Delta 6$	15
	VTG – COURSE OVER GROUND AND GROUND SPEED FORMAT:	17
	ZDA – TIME & DATE FORMAT:	17
6	PROPRIETARY NMEA INPUT SENTENCES.....	18
	GNSS – SATELLITE SYSTEM CONFIGURATION $\Delta 4 \Delta 8$	19
	FIXMASK – SETTING OF POSITIONING AND SATELLITE MASK $\Delta 4$	20
	PPS – SETTING OF PPS (PULSE PER SECOND) $\Delta 4$ FORMAT:	22
	RESTART - RESTART COMMAND $\Delta 4$ FORMAT:	24
	TIME – SETTING OF TIME INFORMATION $\Delta 4$	25
	TIMEZONE – LOCAL ZONE TIME $\Delta 4$	26
	SURVEY – POSITION MODE $\Delta 1$ FORMAT:.....	27
	FREQ – SETTING OF GCLK FREQUENCY $\Delta 2 \Delta 7$ FORMAT:	31
	DEFLS – SETTING OF DEFAULT LEAP SECOND $\Delta 4 \Delta 6$ FORMAT:.....	32
	TIMEALIGN – SETTING OF TIME ALIGNMENT $\Delta 4$ FORMAT:	33
	RESTRICTION:	34
	FLASHBACKUP – SETTING OF BACKUP IN FLASH $\Delta 4$ FORMAT:	35
	CROUT – SETTING OF CR OUTPUT FORMAT:	36
7	CFG – SETTING OF APPLICATION SOFTWARE.....	37
	NMEAOUT – STANDARD NMEA OUTPUT $\Delta 9$	37
	UART1 – SERIAL COMMUNICATION PORT FORMAT:	37
	SYS – PVT SYSTEM	39
	GPIO – GENERAL PURPOSE INPUT/OUTPUT FORMAT:	39

8	PROPRIETARY NMEA OUTPUT SENTENCES	40
	ACK – OUTPUT THE COMMAND RECEPTION CHECK FORMAT:	40
9	CR – ERIDE GNSS CORE LIBRARY INTERFACE	41
	CRW(TPS1) – OUTPUT TIME TRANSFER INFO PER SECOND (DATE AND LEAP SECOND) $\Delta 4 \Delta 5$ FORMAT:	41
	CRX(TPS2) – OUTPUT TIME TRANSFER INFO PER SECOND (PPS) $\Delta 4$ FORMAT:	44
	CRY(TPS3) – OUTPUT TIME TRANSFER INFO PER SECOND (SURVEY & TRAIM) FORMAT:	46
	CRZ (TPS4) – OUTPUT TIME TRANSFER INFO PER SECOND (FREQUENCY) $\Delta 3$ FORMAT:	48
	CRM – MEASUREMENT DATA OF GPS	50
	CRN – NAVIGATION DATA	51
	SYS – ANSWER OF PVT SYSTEM	52
	GPIO- GENERAL PURPOSE INPUT/OUTPUT FORMAT:	52
	FIXSESSION- FIX SESSION $\Delta 1$ FORMAT:	53
	ANTSEL- ANTENNA SELECTING $\Delta 1$ FORMAT:	53
	BBRAM - BATTERY BACKUP RANDOM ACCESS MEMORY $\Delta 1$ FORMAT:	54
	MSG – EVENT DRIVEN MESSAGE $\Delta 1$ FORMAT:	54
10	BACKUP OF THE RECEIVER PARAMETERS (FOR BBRAM) $\Delta 4$	55

1 Communication Specification

Signal Lines used: TXD, RXD
Flow Control: None
System: Full Duplex Asynchronous
Speed: Configurable, Default 38400 bps (*1)
Start Bit: 1 bit
Data Length: 8 bits
Stop Bit: 1 bit
Parity Bit: None
Data Output Interval: 1 second

Character Codes used: NMEA-0183 Ver.4.10 data based

ASCII code (*2) Protocol: Input data

NMEA Standard
sentence NMEA
Proprietary
sentence

Output data

NMEA Standard
sentence NMEA
Proprietary
sentence


Note 1: Communication speed can be changed into 4800, 9600, 19200, 38400, 57600 or 115200 bps.

Please refer to section "UART1 – Serial Communication Port" for how to configure the communication speed. In case of using low baud rate, please adjust size of output sentence by NMEAOUT command and CROUT command to output all sentence within one second.

Note 2: "NMEA 0183 STANDARD FOR INTERFACING MARINE ELECTRONIC DEVICES Version 4.10" (NATIONAL MARINE ELECTRONICS ASSOCIATION, June, 2012)

2 Serial data output timing ^Δ4

The output timing of serial data is synchronous with PPS output timing. Serial data is begun to output in the 25ms to 75ms range after PPS is output.
The time of serial data indicates next PPS output timing.



3 NMEA Sentence Format

13.1 Standard Sentence

Format:

\$	<address field>	,	<data field>	...	*<checksum field>	<CR>	<LF>
----	-----------------	---	--------------	-----	-------------------	------	------

5 bytes

Field	Description
\$	Start-of Sentence marker
<address field>	<p>5-byte fixed length. First 2 bytes represent a talker ID, and the remaining 3 bytes do a sentence formatter.</p> <p>All output sentences must begin with a "\$" followed by a TalkerID. The relevant Talker IDs are GP for GPS, GN for GNSS, GL for GLONASS and GA for Galileo.</p> <p>For the sentences received from external equipment, the GT-87 accepts any talker ID. Talker ID "XX" found on the succeeding pages is a wildcard meaning "any valid talker ID".</p>
<data field>	<p>Variable or fixed-length fields preceded by delimiter ","(comma).</p> <p>Comma(s) are required even when valid field data are not available i.e. null fields. Ex. " , , , , "</p> <p>In a numeric field with fixed field length, fill unused leading digits with zeroes.</p>
<checksum field>	<p>8 bits data between "\$" and "" (excluding "\$" and "*") are XORed, and the resultant value is converted to 2bytes of hexadecimal letters. Note that two hexadecimal letters must be preceded by "*", and delimiter "," is not required before *<checksum>.</p> <p>All output sentences have checksum.</p> <p>For input sentences, the resultant value is checked and if it is not correct, the sentence is treated invalid.</p>
<CR><LF>	End-of-Sentence marker

4 Proprietary Sentence Format:

\$	P	<maker ID>	<sentence type>	,	<data field>	...	*<checksum field>	<CR>	<LF>
		3 bytes	3 bytes						

Field	Description
\$	Start-of-Sentence marker
P	Proprietary sentence identifier
<maker ID>	3-byte fixed length. GT-87's maker ID is "ERD" meaning eRide.
<sentence type>	Indicates the type of sentence.
<data field>	Variable or fixed-length fields preceded by delimiter ","(comma). (Layout is maker-definable.)
<checksum field>	8 bits data between "\$" and "*" (excluding "\$" and "*") are XORed, and the resultant value is converted to 2 bytes of hexadecimal letters. Note that two hexadecimal letters must be preceded by "*", and delimiter "," is not required before *<checksum>. All output sentences have checksum. For input sentences, the resultant value is checked and if it is not correct, the sentence is treated invalid.
<CR><LF>	End-of-Sentence marker

5 Standard NMEA Output Sentences

The receiver supports eight standard NMEA output sentences (GGA, GLL, GNS, GSA, GSV, RMC, VTG and ZDA) per NMEA standard 0183 Version 4.10 (June, 2012).

By default, the RMC, GNS, GSA, ZDA, GSV and TPS sentences will be output every second. The sentences can be independently enabled and disabled using the \$PERDCFG,NMEAOUT and/or \$PERDAPI,CROUT command described later in this document, as well as use differing transmission rates.

The NMEA sentence descriptions in this sentence are for reference only. The sentence formats are defined exclusively by the copyrighted document from NMEA.

eRide does populate all the fields described in the NMEA specification. Uncalculated fields are indicated as "Not Supported".

GGA – Global Positioning System Fix Data Format:

\$XXGGA	,	hhmmss.sss	,	ddmm.mmmm	,	a	,	dddmm.mmmm	,	a	,	x	,	xx	,
		1		2		3		4		5		6		7	
x.x	,	x.x	,	M	,	x.x	,	M	,	xxx	,	xxx	*hh	<CR>	<LF>
8		9		10		11		12		13		14			

#.	Description	Range
1.	UTC	
	"hh": hour	00 - 23
	"mm": minute	00 - 59
	"ss.sss": second	00.000 - 59.999
2-3.	Latitude	
	"dd": degree	00 - 90
	"mm.mmmm": minute	00.0000 - 59.9999
	"a": North/South	N or S
4-5.	Longitude	
	"ddd": degree	000 - 180
	"mm.mmmm": minute	00.0000 - 59.9999
	"a": East/West	E or W
6.	GPS Quality Indication	0 - 2
	"0": Fix not available or invalid	
	"1": Valid fix	
	"2": DGPS positioning	
7.	Number of satellites used for positioning	00 – 12 [*1]
8.	Horizontal dilution of precision (HDOP)	0.0-50.0
	Note: A null field is output while positioning is interrupted.	
9.	Altitude above/below mean sea-level (geoid)	
10.	Unit of Altitude, meter	M
11.	Geoidal height	
12.	Unit of Geoidal height	M
13.	Age of differential GPS data	n/a
14.	Differential reference station ID	n/a

Example:

\$GPGGA,025411.516,3442.8146,N,13520.1090,E,1,11,0.8,24.0,M,36.7,M,,*66

UTC: 02:54:11.516 34 deg 42.8146 min N 135 deg 20.1090 min E

Status: Valid fix Number of satellites: 11 satellites HDOP: 0.8

Altitude: 24.0 meters high Geoidal height: 36.7 meters high

[*1] GPS, SBAS, QZSS only. Galileo and GLONASS are not counted. Upper limit is 12.

GLL – Geographic Position - Latitude/Longitude $\Delta 6$

Format:

\$XXGLL	,	ddmm.mmmm	,	a	,	dddmm.mmmm	,	a	,	hhmmss.sss	,	a	,	a	*hh	<CR>	<LF>
		1		2		3		4		5		6		7			

#	Description	Range
1-2.	Latitude	
	"dd": degree	00 - 90
	"mm.mmmm": minute	00.0000 - 59.9999
	"a": North/South	N or S
3-4.	Longitude	
	"ddd": degree	000 - 180
	"mm.mmmm": minute	00.0000 - 59.9999
	"a": East/West	E or W
5.	UTC	
	"hh": hour	00 - 23
	"mm": minute	00 - 59
	"ss.sss": second	00.000 - 59.999
6.	Status $\Delta 6$	A or V
		"A": Data Valid
		"V": Data Invalid
7.	Position System Mode Indication	A, D or N
		"A": Autonomous
		"D": Differential
		"N": Data Invalid

Example:

\$GPGLL,3442.8146,N,13520.1090,E,025411.516,A,A*5F
 34 deg 42.8146 min N 135 deg 20.1090 min E
 UTC: 02:54:11.516 Mode: Data Valid

GNS – GNSS Fix Data Format:

\$XXGNS	,	hhmmss.sss	,	ddmm.mmmm	,	a	,	dddmm.mmmm	,	a	,	c--c	,	xx	,
		1		2		3		4		5		6		7	
x.x	,	x.x	,	x.x	,	x	,	x	,	x		*hh	<CR>	<LF>	
8		9		10		11		12		13					

#.	Description	Range
1.	UTC	
	"hh": hour	00 - 23
	"mm": minute	00 - 59
	"ss.sss": second	00.000 - 59.999
2-3.	Latitude	
	"dd": degree	00 - 90
	"mm.mmmm": minute	00.0000 - 59.9999
	"a": North/South	N or S
4-5.	Longitude	
	"ddd": degree	000 - 180
	"mm.mmmm": minute	00.0000 - 59.9999
	"a": East/West	E or W
6.	Mode Indicator for each satellite system (GPS, GLONASS, Galileo)	
	"A": Autonomous	
	"D": Differential	
	"N": Data Invalid	
7.	Number of satellites used for positioning	00 - 32
8.	Horizontal dilution of precision (HDOP)	0.0 - 50.0
	Note: A null field is output while positioning is interrupted.	
9.	Altitude above/below mean sea-level (geoid)	
10.	Geoidal height	
11.	Age of differential GPS data	n/a
12.	Differential reference station ID	n/a
13.	Navigation Status Indicator	S, C, U or V
	"S": Safe	
	"C": Caution	
	"U": Unsafe	
	"V": Not Valid	

Example:

\$GNGNS,004457.000,3442.8266,N,13520.1235,E,DDN,22,0.5,40.6,36.7,,,V*60

UTC: 00:44:57.000 34 deg 42.8266 min N 135 deg 20.1235 min E

Status: Data Valid (GPS: differential, GLONASS: differential, Galileo: Invalid)

Number of satellites: 22 satellites HDOP: 0.5

Altitude: 40.6 meters high Geoidal height: 36.7 meters high

Navigation Status Indicator: Not Valid

GSA – GNSS DOP and Active Satellites △4

Format:

\$XXGSA	,	a	,	a	,	xx	,	xx	,	xx	,	...	,	xx	,	x.x	,	x.x	,	x.x	,	h	*hh	<CR>	<LF>
		1		2		3		4		5		6-13		14		15		16		17		18			

#	Description	Range
1.	Operational mode	M or A "M": 2D/3D fixed mode "A": 2D/3D Auto-switching mode
2.	Mode	1 - 3 "1": No fix "2": 2D fix "3": 3D fix
3-14.	Satellite Numbers used for positioning Note: A null field is output unless a satellite is available.	01 - 99
15.	PDOP Note: A null field is output unless 3D-positioning is performed.	0.0 - 50.0
16.	HDOP Note: A null field is output while positioning is interrupted.	0.0 - 50.0
17.	VDOP Note: A null field is output unless 3D-positioning is performed.	0.0 - 50.0
18.	GNSS System ID	n/a

Example:

```
$GNGSA,A,3,09,15,26,05,24,21,08,02,29,28,18,10,0.8,0.5,0.5,1*33
```

```
$GNGSA,A,3,79,69,68,84,85,80,70,83,,,,,0.8,0.5,0.5,2*30
```

2D/3D Auto-switching mode, 3D fix

Satellite used: 09, 15, 26, 05, 24, 21, 08, 02, 29, 28, 10, 79, 69, 68, 84, 85, 80, 70, 83

PDOP: 0.8 HDOP: 0.5 VDOP: 1.5

Notes: △4

- To add extra fields to the GPGSA NMEA string to show more than 12 satellites used in the fix, please input "\$PERDAPI,EXTENDGSA,num*hh<CR><LF>". num is Number of fields for satellites used in the fix. Acceptable values are: 12-16. Default num is 12. By creating more fields for satellites used in the fix, the PDOP/HDOP/VDOP values shift by num12 fields.

- Satellite number means the follow.

Satellite number from 01 to 32 indicates GPS (01 to 32)

Satellite number from 33 to 51 indicates SBAS (120 to 138)

Satellite number from 65 to 92 indicates GLONASS (slot 01 to slot 28)

Satellite number from 93 to 99 indicates QZSS (193 to 199)

GSV – GNSS Satellites in View ^{Δ4}

Format:


\$XXGSV	,	x	,	x	,	x	,	xx	,	xx	,	xxx	,	xx	,	xx	,	xx	,	xxx	,	xx	,
		1		2		3		4		5		6		7		8		9		10		11	

xx	,	xx	,	xxx	,	xx	,	xx	,	xx	,	xxx	,	xx		h	*hh	<CR>	<LF>
12		13		14		15		16		17		18		19		20			

#	Description	Range
1.	Total number of messages	1 - 4
2.	Number of messages	1 - 4
3.	Number of satellites in line-of-sight	00 - 14
4.	1 st Sat. ID number	01 - 99
5.	1 st Sat. elevation angle (degree)	00 - 90
6.	1 st Sat. azimuth angle (degree)	000 - 359
7.	1 st Sat. SNR (Signal/Noise Ratio) (dB)	00 - 99
8-11.	2 nd Sat. Details	
12-15.	3 rd Sat. Details	
16-19.	4 th Sat. Details	
20.	Signal ID	

Example:

```
$GPGSV,4,1,14,15,67,319,52,09,63,068,53,26,45,039,50,05,44,104,49,1*6E
$GPGSV,4,2,14,24,42,196,47,21,34,302,46,18,12,305,43,28,11,067,41,1*68
$GPGSV,4,3,14,08,07,035,38,29,04,237,39,02,02,161,40,50,47,163,44,1*67
$GPGSV,4,4,14,42,48,171,44,93,65,191,48,,,,,,,,,1*60
$GLGSV,3,1,09,79,66,099,50,69,55,019,53,80,33,176,46,68,28,088,45,1*76
$GLGSV,3,2,09,70,25,315,46,78,24,031,42,85,18,293,44,84,16,246,41,1*7A
$GLGSV,3,3,09,86,02,338,,,,,,,,,1*45
```



<checksum><CR><LF> is output right after the last satellite data output.

Notes: ^{Δ4}

- In this sentence, a maximum of four satellite details is indicated per each output. Five or more satellite details are output in the 2nd or 3rd messages. When there is an item which is not fixed in the satellite details, a null field is output. When there are only one to four satellite details, <checksum><CR><LF> is issued immediately after Sat. SV#, Sat. elevation angle, Sat. azimuth angle and SNR.

- Satellite number means the follow.

Satellite number from 01 to 32 indicates GPS (01 to 32)

Satellite number from 33 to 51 indicates SBAS (120 to 138)

Satellite number from 65 to 92 indicates GLONASS (slot 01 to slot 28)

Satellite number from 93 to 99 indicates QZSS (193 to 199)

RMC – Recommended Minimum Navigation Information^{Δ6}

Format:

\$XXRMC	,	hhmmss.sss	,	a	,	ddmm.mmmm	,	a	,	dddmm.mmmm	,	a	,	x.x	,
		1		2		3		4		5		6		7	
x.x	,	ddmmyy	,	x.x	,	a	,	a	,	a	*	hh	<CR>	<LF>	
8		9		10		11		12		13					

#	Description	Range
1.	UTC	
	"hh": hour	00 - 23
	"mm": minute	00 - 59
	"ss.sss": second	00.000 - 59.999
2.	Status ^{Δ6}	A or V
	"A": Data valid	
	"V": Data not valid	
3-4.	Latitude	
	"dd": degree	00 - 90
	"mm.mmmm": minute	00.0000 - 59.9999
	"a": North/South	N or S
5-6.	Longitude	
	"ddd": degree	000 - 180
	"mm.mmmm": minute	00.0000 - 59.9999
	"a": East/West	E or W
7.	Speed (kts)	
8.	True Course (degree)	
9.	Date	
	"dd": date	
	"mm": month	
	"yy": last two digits of the year	
10.	Magnetic declination	
	Note: A null field is output unless magnetic declination information is available.	
11.	Correction direction of magnetic declination	
	Note: A null field is output unless magnetic declination information is available.	
12.	Positioning System Mode Indication	A, D or N
	"A": Autonomous	
	"D": Differential	
	"N": Data Invalid	
13.	Navigation Status Indicator	S, C, U or V
	"S": Safe	
	"C": Caution	
	"U": Unsafe	
	"V": Not Valid	

Example:

\$GNRMC,012344.000,A,3442.8266,N,13520.1233,E,0.00,0.00,191132,,,D,V*0B

UTC: 01:23:44.000 Differential 34 deg 42.8266 min N 135 deg 20.1233 min E

Speed: 0.0 kts True Course: 0.0 degrees UTC Date: Nov 19, 2032

VTG – Course Over Ground and Ground Speed Format:

\$XXVTG	,	x.x	,	T	,	x.x	,	M	,	x.x	,	N	,	x.x	,	K	,	a	*hh	<CR>	<LF>
		1		2		3		4		5		6		7		8		9			

#	Description	Range
1-2.	True Course (degree) "T" (meaning TRUE)	T
3-4.	Magnetic Direction "M" (meaning Magnetic Direction) Note: A null field is output unless magnetic direction information is available.	M
5-6.	Speed (kts) "N" (meaning knot)	N
7-8.	Speed (km/h) "K" (meaning km/h)	K
9.	Positioning System Mode Indication "A": Autonomous "D": Differential "N": Data Invalid	A, D or N

Example:

\$GNVTG,0.00,T,,M,0.00,N,0.00,K,D*26

True Course: 0.00 degrees Speed: 0.00 kts, 0.00 km/h Mode: Differential

ZDA – Time & Date Format:

\$XXZDA	,	hhmmss.sss	,	xx	,	xx	,	xxxx	,	xxx	,	xx	*hh	<CR>	<LF>
		1		2		3		4		5		6			

#	Description	
1.	UTC: Time "hh": hour "mm": minute "ss.sss": second	00 - 23 00 - 59 00.000 - 59.999
2.	UTC: Day of Month	01 - 31
3.	UTC: Month	01 - 12
4.	UTC: Year	1999 - 2099 _{Δ3}
5.	Local Zone Hours	(+/-) 00 - 23
6.	Local Zone Minutes	00 - 59

Example:

\$GPZDA,014811.000,13,09,2013,+00,00*7B

UTC: 01:48:11.000 13th September, 2013

6 Proprietary NMEA Input Sentences

These sentences are input commands for the protocol of this receiver.

GNSS – Satellite System Configuration $\Delta 4 \Delta 8$

Format:

\$PERDAPI	,	GNSS	,	talkerID	,	gps	,	glonass	,	galileo	,	qzss	,	sbas	*hh	<CR>	<LF>
		1		2		3		4		5		6		7			

Num	Contents	Range	Default	Remark
1	GNSS	-	-	Command Name
2	talkerID	AUTO, LEGACYGP or GN $\Delta 8$	AUTO	AUTO: GLGSV is omitted in case of no glonass. GPGSV is omitted in case of no GPS, SBAS and QZSS. LEGACYGP: GL and GN sentence is omitted. GN: GLGSV is output even if no glonass. GPGSV is output even if no GPS, SBAS and QZSS.
3	gps	0 or 2	2	GPS mode $\Delta 3$
4	glonass	0 or 2	2	Glonass mode $\Delta 3$
5	galileo	0	0	Galileo mode (unimplemented)
6	qzss	0 or 2	2	Qzss mode $\Delta 3$
7	sbas	0, 1 or 2	1	Sbas mode $\Delta 2$

Example:

\$PERDAPI,GNSS,AUTO,2,2,0,2,2*41

Use: GPS, GLONASS, QZSS, SBAS

Mask: Galileo

Notes: $\Delta 4$

- This command controls which Global Navigation Satellite Systems are used by the receiver. The mode can be set to 0 or 2 for each satellite system. User can also set SBAS mode to 1. Mode 0 means to disable the system.

Mode 1 means to enable tracking only (do not use in position fix etc).

Mode 2 means to enable tracking and use the in position fix calculation.

- In GT-87, default setting of SBAS mode is 1, because to use calculation data of SBAS tends to reduce the accuracy of 1PPS. Therefore although GT-87 becomes to differential fix, SBAS is not appeared in GSA sentence in default setting.

- The response which is inserted current value to each field is obtained by receiving an effective command for setting or inputting a command which is omitted the fields after Command Name, that is, \$PERDAPI,GNSS,QUERY*18.

- "Sbas only configuration" and "No tracking configuration" are not accepted.

\$PERDAPI,GNSS,AUTO,0,0,0,0,2*43

\$PERDAPI,GNSS,AUTO,0,0,0,0,1*40

\$PERDAPI,GNSS,AUTO,0,0,0,0,0*41

- Cold restart (time also be cleared) is run when satellite system configuration is changed from/to glonass only fix configuration. In the others configuration, hot restart is run.

FIXMASK – Setting of Positioning and Satellite Mask ^{Δ4}

Format:

\$PERDAPI	,	FIXMASK	,	mode	,	elevmask	,	Reserve1	,	snrmask	,	Reserve2	[,
		1		2		3		4		5		6	

Prohibit SVs (GPS)	,	Prohibit SVs (GLONASS)	,	Prohibit SVs (Galileo)	,	Prohibit SVs (QZSS)	,	Prohibit SVs (SBAS)]	*hh	<CR>	<LF>
7		8		9		10		11			

Num	Contents	Range	Default	Remark
1	FIXMASK	-	-	Command Name
2	mode	USER	-	Fixed Value
3	elevmask	0 to 90	0	Elevation mask (in degree) Only SVs whose age is within this threshold are used in the position fix calculation.
4	Reserve1	0	0	Reserve field
5	snrmask	0 to 99	0	Signal level mask (in dB-Hz) Only SVs above this mask are fixed.
6	Reserve2	0	0	Reserve field
7	Prohibit SVs (GPS)	32BIT (HEX)	0	GPS Satellite number mask Each bit represents one SVID. The GPS satellites indicated by this field are not used in the position fix calculation. Lowest order bit means SV=01. Highest order bit means SV=32. ^{Δ4}
8	Prohibit SVs (GLONASS)	28BIT (HEX)	0	GLONASS Satellite number mask Each bit represents one SVID. The GLONASS satellites indicated by this field are not used in the position fix calculation. Lowest order bit means SV=65. Highest order bit means SV=92. ^{Δ4}
9	Prohibit SVs (Galileo)	20BIT (HEX)	0	Galileo Satellite number mask Each bit represents one SVID. This field is unimplemented. ^{Δ4}
10	Prohibit SVs (QZSS)	7BIT (HEX)	0	QZSS Satellite number mask Each bit represents one SVID. The QZSS satellites indicated by this field are not used in the position fix calculation. Lowest order bit means SV=93. Highest order bit means SV=99. ^{Δ4}
11	Prohibit SVs (SBAS)	19BIT (HEX)	0	SBAS Satellite number mask Each bit represents one SVID. The SBAS satellites indicated by this field are not used in fix. Lowest order bit means SV=33. Highest order bit means SV=51. ^{Δ4}

Example:

\$PERDAPI, FIXMASK, USER, 10, 0, 37, 0, 0x92, 0x01, 0x00, 0x00, 0x20000*50

Elevation mask: 10 degrees

Signal level mask: 37 dBHz

GPS mask: GPS (BIT2 = SVID 2), GPS (BIT5 = SVID 5) and GPS (BIT9 = SVID 9)

GLONASS mask: GLONASS (BIT1 = SVID 65)

SBAS mask: SBAS (BIT18 = SVID 50)

Notes:

- It is applied not only to First Fix or the time of a positioning return but to all the positioning.
- It is omissible after the 7th field.
- The response which is inserted current value to each field is obtained by receiving an effective command for setting or inputting a command which is omitted the fields after Command Name, that is, \$PERDAPI, MASK, QUERY*50.

PPS – Setting of PPS (Pulse per second) Δ 4 Format:

\$PERDAPI	,	PPS	,	type	,	mode	,	period	,	pulse width	,	cable delay	,
		1		2		3		4		5		6	

polarity	[PPS accuracy threshold]	*hh	<CR	<LF>
7		8			

Num	Contents	Range	Default	Remark
1	PPS	-	-	Command Name
2	type	LEGACY GCLK	LEGACY	PPS type
3	mode	0 to 4	4	PPS mode 0: Always stop 1: Always output 2: Output only during positioning more than one satellite 3: Output only when TRAIM is OK 4: Output only when estimated accuracy is less than estimated accuracy threshold which is 8th field on this command.
4	period	0 to 1	0	PPS output interval 0: 1PPS (A pulse is output per second) 1: PP2S (A pulse is output per two seconds)
5	pulse width	1 to 500	200	PPS pulse width (ms)
6	cable delay	-100000 to 100000	0	PPS cable delay (ns) Plus brings delay PPS. Minus brings forward PPS.
7	polarity	0 to 1	0	PPS polarity (LEGACY PPS is rising edge only) 0 : rising edge 1 : falling edge
8	PPS accuracy threshold	5 to 9999	1000	PPS estimated accuracy threshold This threshold is used for mode 4. Δ 4

Example:

```
$PERDAPI,PPS,LEGACY,1,0,200,0,0,25*29
```

Type: LEGACY PPS Mode: Always output

1PPS Pulse width: 200 ms cable delay: 0 ns

Polarity: rising edge of PPS is synchronous with UTC time.

PPS estimated accuracy threshold is 25nsec.

Notes: △4

- LEGACY PPS setting is output legacy PPS which is not synchronized with frequency which is output from GCLK pin, but which is output immediately after first fix in case of cold start.
- GCLK PPS setting is output GCLK PPS which synchronized with frequency which is output from GCLK pin, but it takes some to become GCLK PPS steady after first fix (typically, 1~2 minutes after first fix). User can confirmed whether GCLK PPS is steady by GCLK accurate field of TPS4 sentence.
- User can choose GPS, UTC (USNO) and UTC (SU) as alignment of PPS by TIMEALIGN command. The default is UTC (USNO). As for details, please refer to the page of TIMEALIGN command.
- The condition of PPS synchronization is the follow.

[1] GPS alignment

PPS mode	Before first fix	After first fix
0	OFF	OFF
1	Sync with RTC	Sync with GPS
2~4	OFF	Sync with GPS

[2] UTC (USNO) alignment (default)

PPS mode	Before first fix	After first fix	After taking UTC (USNO) parameter from GPS
0	OFF	OFF	OFF
1	Sync with RTC	Sync with GPS	Sync with UTC (USNO)
2~4	OFF	Sync with GPS	Sync with UTC (USNO)

[3] UTC (SU) alignment

PPS mode	Before first fix	After first fix	After taking UTC (SU) parameter from GLONASS
0	OFF	OFF	OFF
1	Sync with RTC	Sync with GPS	Sync with UTC (SU)
2~4	OFF	Sync with GPS	Sync with UTC (SU)

- About PPS estimated accuracy, please refer to the page of CRX (TPS2) sentence.

RESTART - Restart command $\Delta 4$ Format:

\$PERDAPI	,	RESTART	,	restart mode	*hh	<CR>	<LF>
1		2					

Num	Contents	Range	Default	Remark
1	RESTART	-	-	Command Name
2	restart mode	HOT WARM COLD FACTORY	-	Restart mode

Example:

\$PERDAPI,RESTART,COLD*08

Mode: cold restart

Notes: $\Delta 4$

- As for the differences depending on the restart mode, please refer to the page of "Backup of the Receiver Parameters (for BBRAM)".
- The data which is stored by FLASHBACKUP command in Flash is not cleared even if FACTORY restart is occurred.
- Power off/on of GT-87 corresponds to hot restart when it is within 4 hours after last fix.
- Power off/on of GT-87 corresponds to warm restart when it is over 4 hours after last fix.

TIME – Setting of time information $\Delta 4$

Initial time is configured. The setting of time is effective only within the case that time is not decided by other factors. A setting of a millennium which is the times of GPS week rollover is received also after time decision.

Format:

\$PERDAPI	,	TIME	,	time of date	,	day	,	month	,	year	*hh	<CR>	<LF>
		1		2		3		4		5			

Num	Contents	Range	Default	Remark
1	TIME	-	-	Command Name
2	Time of date	00 to 23 00 to 59 00 to 59	0	UTC (Hour) UTC(Minute) UTC(Second)
3	day	1 to 31	22	UTC (Date)
4	month	1 to 12	8	UTC (Month)
5	year	2013 to 2099	1999	UTC (Year) $\Delta 3$

Example:

\$PERDAPI,TIME,021322,24,11,2020*64

Time: 02:13:22 on 24th November, 2020

Notes: $\Delta 4$

- This command is needed to input correct date within +/- 1 year.
- Under normal conditions, User needs not to set initial time because time is decided by satellite navigation data.
- As for GPS week rollover timing and GT-87 week rollover timing, please refer to the follow.

event	date	GPS week
GPS week rollover timing (1st) default time of date of GT-87	1999/08/22	1024
GPS week rollover timing (2nd)	2019/04/07	2048
rollover timing of GT-87	2032/08/15	2745
GPS week rollover timing (3rd)	2038/11/21	3072
...		
operable time limit of GT-87	2099/12/31	6260

[In case that GT-87 does not have glonass]

GT-87 can keep outputting correct date after 2032/08/15 during power distribution.

GT-87 will output 2012/12/30 after 2032/08/15 unless user sets correct date by TIME command after user turns off GT-87 and also turns off backup current for BBRAM.

[In case that GT-87 has glonass]

GT-87 can adjust millennium automatically in the timing of first fix of glonass and outputs correct date until 2099/12/31 without user setting even if user turns off GT-87 and backup current.

TIMEZONE – Local Zone Time $\Delta 4$

This sentence is reflected to ZDA sentence (not only local zone field but also UTC time field).

Format:

\$PERDAPI	,	TIMEZONE	,	sign	,	hour	,	minute	*hh	<CR>	<LF>
		1		2		3		4			

Num	Contents	Range	Default	Remark
1	TIMEZONE	-	-	Command Name
2	sign	0 to 1	0	GMT sign "0" shows positive, "1" shows negative.
3	hour	0 to 23	0	GMT (Hour)
4	minute	0 to 59	0	GMT (Minute)

Example:

\$PERDAPI,TIMEZONE,0,9,0*69

As GMT offset, display time is carried out +9:00.

Notes: $\Delta 4$

- In UTC (SU) alignment, GMT offset is changed to +3:00 automatically.

SURVEY – Position Mode Δ 1 Format:

\$PERDAPI	,	SURVEY	,	position mode	[,	sigma threshold	,	time threshold]
1				2		3		4

[,	latitude	,	longitude	,	altitude]]	*hh	<CR>	<LF>
	5		6		7			

Num	Contents	Range	Default	Remark
1	SURVEY	-	-	Command Name
2	position mode	0 to 3	2	0: Normal NAV (navigation) mode 1: Position Survey SS (self survey) mode 2: Position Survey CSS (continual self survey) mode 3: Position-hold TO (time only) mode
3	sigma threshold	0 to 255	0 Δ 3	Sigma threshold (m) which changes automatically to position-fixed. (When the threshold value is 0, it is not used.)
4	time threshold	0 to 10080	480 (8hours) Δ 3	Time threshold (minute) which changes automatically to position-fixed. (When the threshold value is 0, it is not used.)
5	latitude Δ 1	-90 to 90	0	Latitude for hold position in TO mode. (degree) A positive number means the north latitude and a negative number means the south latitude. This field can be set only when position mode is 3.
6	longitude Δ 1	-180 to 180	0	Longitude for hold position in TO mode. (degree) A positive number means the east longitude and a negative number means the west longitude. This field can be set only when position mode is 3.
7	altitude Δ 1	-1000 to 18000	0	Altitude for hold position in TO mode. (m) This field can be set only when position mode is 3.

Example:

\$PERDAPI,SURVEY,1,10,1440*74

Mode: SS mode Sigma Threshold: 10 Time Threshold: 1440


\$PERDAPI,SURVEY,3,0,0,37.78700,-122.45100,31.5*53

Mode: TO mode Sigma Threshold: 0 Time Threshold: 0

Fixed position: 37.78700 degrees north 122.45100 degrees west Altitude: 31.5 m

Notes:

- It is omissible after the 3rd field.
- When the position mode is "1", a position is re-calculated after power supply OFF/ON. Please use it, when the antenna position may change before power supply OFF.
- When the position mode is "2", after power supply OFF/ON, the estimated position that calculated before power supply OFF is kept, and the position is updated. By using it when the antenna position does not change after the power supply OFF, the time for changing to Position-hold mode can be shortened.
- In order to change automatically to Position-hold mode, it is necessary to set to Survey mode.
- If both sigma threshold and time threshold are configured, the position mode changes to Position-hold mode when either is fulfilled. When the threshold value is 0, it is not used.
- The displayed position may differ a little from the configured position due to conversion error.
- Hot start is occurred when survey mode is shift to NAV mode. Δ1



Flow chart about position mode

	Transition condition	Whether keep or not survey position and number of times of survey process
A	After first power on, or after factory restart (default)	Discard
B	After power on in case that last mode is "SURVEY,0".	Discard
C	After power on in case that last mode is "SURVEY,1".	Discard
D	After power on in case that last mode is "SURVEY,2".	Keep
E	After power on in case that last mode is "SURVEY,3".	Keep
F	"SURVEY,0" command	Discard
G	"SURVEY,3" after self survey position is fixed. "SURVEY,3" with user's hold position.	Keep
H	"SURVEY,1" command	Discard
I	"SURVEY,2" command	Discard

J	The condition of survey is satisfied. [*] Position mode is always started by time only mode if TO mode by this condition and power off.	Keep
---	--	------

FREQ – Setting of GCLK FREQUENCY $\Delta 2 \Delta 7$ Format:

\$PERDAPI	,	FR	,	mode	,	freq	[,	duty	,	offset]	*hh	<CR>	<LF>
		1		2		3		4		5			

Num	Contents	Range	Default	Remark
1	FREQ	-	-	Command Name
2	mode	0 to 1	0	0 : stop 1 : output
3	freq	4000 to 40000000	10000000 (10MHz)	frequency[Hz]
4	duty $\Delta 2$	10 to 90 $\Delta 7$	50	duty cycle [%]
5	offset $\Delta 2$	0 to 99	0	phase delay in cycle [%] from GCLK-PPS edge

Example:


```
$PERDAPI,FREQ,1,10000000*47
```

Mode: output

Frequency: 10MHz

Notes:

- It is omissible after the 4th field.
- The response which is inserted current value to each field is obtained by receiving an effective command for setting or inputting a command which is omitted the fields after Command Name, that is, \$PERDAPI,FREQ,QUERY*11.
- Duty cycle is derived from T_{high} / T_{cycle} in the follow figure. $\Delta 2$
- User can stock current FREQ command setting on Flash by FLASHBACKUP command.



DEFLS – Setting of default leap second $\Delta 4 \Delta 6$ Format:

\$PERDAPI	,	DEFLS	,	sec	[,	mode]	*hh	<CR>	<LF>
		1		2		3			

Num	Contents	Range	Default	Remark
1	DEFLS	-	-	Command Name
2	sec	0 to 32	16	Default leap second
3	mode	AUTO or FIXED	AUTO	AUTO: default leap second is updated automatically after taking leap second from satellites. FIXED: default leap second is kept as user setting.

Example:

\$PERDAPI,DEFLS,16,AUTO*27

Default leap second: 16 second (this value is updated automatically).

Notes:

- It is omissible after the 3rd field.
- This value is used before leap second is confirmed by other factors which are to take UTC (USNO) parameter which is broadcasted from GPS or to take time difference between GPS and GLONASS.
- GT-87 can store current DEFLS command setting in Flash by FLASHBACKUP command.
- Cold restart (time also be cleared) is run when this command is run. $\Delta 6$

TIMEALIGN – setting of time alignment $\Delta 4$ Format:

	1		2				
\$PERDAPI	,	TIMEALIGN	,	mode	*hh	<CR>	<LF>

Num	Contents	Range	Default	Remark
1	TIMEALIGN	-	-	Command Name
2	mode	1 to 3	2	1 : GPS alignment 2 : UTC(USNO) alignment 3 : UTC(SU) alignment

Example:

```
$PERDAPI,TIMEALIGN,2*31
UTC (USNO) alignment
```

Notes:

- Please note that mode 0 is invalid value.
- User can store current TIMEALIGN command setting on Flash by FLASHBACKUP command.
- This command is used to set output time alignment and 1PPS alignment.

[1: GPS alignment]

- Leap second is not applied to output time even if GT-87 already has leap second.
- PPS is output in synchronization with GPS even if GT-87 already has UTC parameter.
- In Glonass only mode, correct default leap second is needed to output correct time.

[2: UTC (USNO) alignment]

- Leap second is applied to output time.
- PPS is output in synchronization with GPS before taking UTC (USNO) parameter from GPS.
- PPS is output in synchronization with UTC(USNO) after taking UTC (USNO) parameter from GPS.
- In Glonass only fix, because GT-87 can't take UTC (USNO) parameter from GLONASS, PPS is kept to output in synchronization with GPS.

[3: UTC (SU) alignment]

- Leap second is applied to output time. And, GMT offset is set as +3:00.
- PPS is output in synchronization with GPS before taking UTC (SU) parameter from GLONASS.
- PPS is output in synchronization with UTC(SU) after taking UTC (SU) parameter from GLONASS.
- In GPS only fix, because GT-87 can't take UTC (SU) parameter from GPS, PPS is kept to output in synchronization with GPS.

Restriction:

Output time

	GPS only fix setting	GLONASS only fix setting	GPS + GLONASS setting
GPS alignment	OK	accurate default leap second is required [*1]	OK
UTC(USNO) alignment	OK	OK	OK
UTC(SU) alignment	OK	OK	OK

PPS

	GPS only fix setting	GLONASS only fix setting	GPS + GLONASS setting
GPS alignment	OK	OK	OK
UTC(USNO) alignment	OK	NG	OK
UTC(SU) alignment	NG	OK	OK

[*1] In GPS alignment and GLONASS only fix setting, to output correct output time, user needs to set accurate default leap second by DEFLS command.

- In this graph, QZSS is treated as GPS.

FLASHBACKUP – Setting of backup in Flash Δ 4 Format:

\$PERDAPI	,	FLASHBACKUP	,	type	*hh	<CR>	<LF>
		1		2			

Num	Contents	Range	Default	Remark
1	FLASHBACKUP	-	-	Command Name
2	type	0x00 to 0x07 (HEX)	0x00	Target of backup Each bit represents one command setting 0x01 : FREQ command setting 0x02 : DEFLS command setting 0x04 : TIMEALIGN command setting 0x00 means that flash backup is initialised.

Example:

\$PERDAPI,FLASHBACKUP,0x03*4E

Current setting of FREQ and DEFLS command is stored in flash.

Notes:

- This data stored in Flash is erased when software update.
- This data stored in Flash is not erased by factory cold restart.
- Hot start is occurred when this command is input.
- Please don't turn off GT-87 during this command is sent.

Restriction:

GT-87 has two ways to backup data.

[1] BBRAM

BBRAM is RAM which is available to store data as long as backup current is impressed. GT-87 can store ephemeris data, almanac data and configuration which user sets by commands etc in BBRAM, and the data is not erased even if GT-87 is turned off.

The backup timing of BBRAM is every second. The data is cleared when user inputs RESTART command and/or user turns off backup current.

[2] FLASH

GT-87 can store FREQ command setting, DEFLS command setting and/or TIMEALIGN command setting in flash when user inputs FLASHBACKUP command. The data is not erased even if GT-87 is turned off or RESTART command. The data is cleared when user inputs FLASHBACKUP command or software update.

If GT-87 has different backup data between BBRAM and Flash, BBRAM data have a priority over flash. In this case, when the data of BBRAM is invalid because that backup current is turned off, Flash data is applied.

CROUT – Setting of CR Output Format:

\$PERDAPI	,	CROUT	,	type	,	rate	*hh	<CR>	<LF>
		1		2		3			

Num	Contents	Range	Default	Remark
1	CROUT	-	-	Command Name
2	type	N,M,W,X,Y,Z	W,X,Y,Z	Output CR sentence [*] Alphabets of outside range are reserved.
3	rate	W,X,Y,Z : 0 to 255 N,M : 0 to 1	1	W,X,Y,Z : 1-255:Update interval of the sentence (sec) 0: The sentence(s) is/are stopped. N,M : 1: Sentence(s) is/are output every event occurred. 0: The sentence(s) is/are stopped.

Example:

\$PERDAPI,CROUT,W,1*4E
CRW (TPS1) sentence is output every second.

\$PERDAPI,CROUT,XZ,3*19
CRX (TPS2) sentence and CRZ(TPS4) sentence are output every 3 seconds.

\$PERDAPI,CROUT,W,0*4F
CRW (TPS1) sentence is stopped.

\$PERDAPI,CROUT,N,1*57
CRN sentence is output every event occurred.

Notes:

- "M" or/and "N" can be output only in case that baud rate is 115200bps. Δ1

7 CFG – Setting of Application Software

NMEAOUT – Standard NMEA Output ⁴⁹

Format:

\$PERDCFG	,	NMEAOUT	,	type	,	interval	*hh	<CR>	<LF>
		1		2		3			

Num	Contents	Range	Default	Remark
1	NMEAOUT	-	-	Command Name
2	type	[*1]	-	Standard NMEA sentence [*1] GGA, GLL, GNS, GSA, GSV, RMC, VTG, ZDA, ALL ^Δ 9. (ALL means all sentences from GGA to ZDA.)
3	Interval	0 to 255	-	Update interval of the sentence (sec) When the value is "0", the sentence is output only once. After that, the sentence is stopped.

Example:

\$PERDCFG,NMEAOUT,GGA,2*57

Interval: 2 seconds

\$PERDCFG,NMEAOUT,GSV,0*56

GSV sentence is output only once. After that, GSV sentence is stopped.

UART1 – Serial Communication Port Format:

\$PERDCFG	,	UART1	,	baud	*hh	<CR>	<LF>
		1		2			

Num	Contents	Range	Default	Remark
1	UART1	-	-	Command Name
2	baud	4800, 9600, 19200, 38400, 57600 or 115200	38400	Baud rate (bps)

Example:

\$PERDCFG,UART1,115200*65

Baud rate: 115200 bps

Notes:

- When the setting of the serial communication port is changed by this command, ACK sentence is output by the baud rate which was being used.

- In case of using low baud rate, please adjust size of output sentence by NMEAOUT command and CROUT command to output all sentence within one second.

SYS – PVT System

1.2 VERSION – Software Version

Format:

\$PERDSYS	,	VERSION	*hh	<CR>	<LF>
-----------	---	---------	-----	------	------

1

Num	Contents	Range	Default	Remark
1	VERSION	-	-	Command Name

Example:

\$PERDSYS,VERSION*2C

GPIO – General Purpose Input/output Format:

\$PERDSYS	,	GPIO	*hh	<CR>	<LF>
-----------	---	------	-----	------	------

1

Num	Contents	Range	Default	Remark
1	GPIO	-	-	Command Name

Example:

\$PERDSYS,GPIO*67

8 Proprietary NMEA Output Sentences

This sentence is a protocol only for our company. It starts from "\$PERD" which shows that it is an original sentence.

ACK – Output the Command Reception Check Format:

\$PERDACK	,	command	,	sequence	,	subcommand	*hh	<CR>	<LF>
		1		2					

Num	Contents	Range	Default	Remark
1	command	-	-	First field of received command
2	sequence	-1 to 255	0	The number of times successful for the reception. It is added 1 whenever it succeeds in command reception, and 0 to 255 is repeated. When command reception is failed, -1 is returned.
3	subcommand	-	-	Second token of input command

Example:

\$PERDACK,PERDAPI,-1,PPS*72

PERDAPI,PPS command input is failed.

Notes:

- As for the command, check sum must be effective before ACK is sent.

9 CR – eRide GNSS Core Library Interface

CRW(TPS1) – Output Time Transfer Info per Second (Date and leap second)

Δ4Δ5 Format:

\$PERDCRW	,	TPS1	,	Date & Time	,	time status	,	update date	,	present LS	,
		1		2		3		4		5	

future LS	,	pps status	*hh	<CR	<LF>
		6		7	

Num	Contents	Range	Default	Remark
1	TPS1	-	-	Command Name
2	Date & Time	14-byte fixed length	199908220000000	Present date and time year, month, day, hour, minute, second
3	time status	0 to 2 (1byte)	0	Present time status of output sentence 0: RTC 1: GPS (GT-87 doesn't apply leap second or has only default leap second) 2: UTC (GT-87 has confirmed leap second and applies it.)
4	update date	14-byte fixed length	000000000000000	Leap second update schedule year, month, day, hour, minute, second This date indicates zero when no leap second update schedule.
5	present LS	-31 to +32 (3byte)	+16 Δ5	Present leap second received from satellites
6	future LS	-31 to +32 (3byte)	+00	Future leap second received from satellites
7	pps status Δ4	0 to 3 (1byte)	0	Present pps is synced with the follow. 0:RTC 1:GPS 2:UTC(USNO) 3:UTC(SU)

Example:

\$PERDCRW,TPS1,20120303062722,2,20120701000000,+15,+16,2*09

Present date: 2012/03/03 06:27:22

Time status: present time of output sentence is sync with UTC.

Leap second update schedule: 2012/7/1 00:00:00

Current leap second: +15

Future leap second: +16

Pps status: present pps is sync with UTC (USNO)

Notes:

- This command is output every second.
- Present LS is current leap second. This is updated in the timing of leap second update schedule.
- \$PERDAPI,CROUT,W,0*4F stops outputting this command.
- Update data indicate zero when no update schedule.

Restriction:

About time status

alignment	Before first fix	After first fix	After taking confirmed leap second
GPS	RTC	GPS	GPS
UTC(USNO)	RTC	GPS	UTC
UTC(SU)	RTC	GPS	UTC

About leap second which is used to adjust output time

alignment	Before first fix	After first fix	After taking confirmed leap second
GPS	0	0	0
UTC(USNO)	Default leap second	Default leap second	confirmed leap second
UTC(SU)	Default leap second	Default leap second	confirmed leap second

GT-87 takes confirmed leap second when GT-87 takes UTC (USNO) parameter which is broadcasted from GPS or takes time both GPS and GLONASS.

CRX(TPS2) – Output Time Transfer Info per Second (PPS) Δ 4 Format:

\$PERDCRX	,	TPS2	,	pps status	,	pps mode	,	pps period	,	pulse width	,	cable delay
		1		2		3		4		5		6

,	polarity	,	pps type	,	estimated accuracy	,	Sawtooth	,	pps acc threshold	*hh	<CR>	<LF>
	7		8		9		10		11			

Num	Contents	Range	Default	Remark
1	TPS2	-	-	Command Name
2	pps status	0 to 1 (1byte)	0	Output status of 1PPS 0: 1PPS OFF 1: 1PPS ON
3	pps mode	0 to 4 (1byte)	4	PPS mode 0: Always stop 1: Always output 2: Output only during positioning more than one satellite 3: Output only when TRAIM is OK 4: Output only when estimated accuracy is less than estimated accuracy threshold
4	period	0 to 1 (1byte)	0	1PPS output interval 0: 1PPS (A pulse is output per second) 1: PP2S (A pulse is output per two seconds)
5	pulse width	001 to 500 (3byte)	200	1PPS pulse width (ms)
6	cable delay	-100000 to +100000 (7byte)	+000000	1PPS cable delay (ns)
7	polarity	0 to 1 (1byte)	0	0 : rising edge 1 : falling edge
8	pps type	0 to 1 (1byte)	0	0 : LEGACY PPS 1 : GCLK PPS
9	estimated accuracy	0000 to 9999 (4byte)	0	1PPS estimated accuracy. (ns)
10	Sawtooth	-1.760 to +1.760 (6byte)	+0.000	Sawtooth correction (ns)
11	pps acc threshold	0000 0005 to 9999 (4byte)	1000	PPS estimated accuracy threshold (ns) This threshold is used for pps mode 4. 0 means that this threshold is not used.

\$PERDCRX,TPS2,1,2,0,200,+001000,0,0,0005,+0.000,1000*29

PPS status: PPS ON (1)

PPS mode: during on fix (2)

PPS period: 1PPS (0)

PPS pulse width: 200ms

PPS cable delay: +1000ns

Polarity: rising edge

Type: LEGACY PPS

Estimated accuracy: 5ns

Sawtooth: +0.000ns

PPS estimated accuracy threshold: 1us

Notes:

- This command is output every second.
 - \$PERDAPI,CROUT,X,0*40 stops outputting this command.
 - Output Values of period, pulse width, polarity are switched by pps type (LEGACY or GCLK).
 - PPS estimated accuracy means estimated difference between PPS of GT-87 and GPS, UTC (USNO) or UTC (SU) timing which user sets by TIMEALIGN command. This is not guarantee value, but user can use this value to get a rough idea.
 - Sawtooth means correction value under the resolution of GT-87, that is, about 3.5 ns.
 - Sawtooth value is applied to prior to the one second PPS.
- Corrected PPS [t-1] = output PPS [t-1] + Sawtooth value [t]

CRY(TPS3) – Output Time Transfer Info per Second (Survey & TRAIM) Format:

\$PERDCRY	,	TPS3	,	pos mode	,	sigma	,	sigma threshold	,	time	,	time threshold	,
		1		2		3		4		5		6	

TRAIM solution	,	TRAIM status	,	Removed SVs	,	Receiver status	*hh	<CR>	<LF>
		7		8		9		10	

Num	Contents	Range	Default	Remark
1	TPS3	-	-	Command Name
2	pos mode	0 to 3 (1byte)	2	Positioning mode 0: Normal 1: Survey mode (re-calculation for every power supply OFF/ON) 2: Survey mode(calculation continuously before and after power supply OFF/ON) 3: Position-hold mode
3	sigma	0000 to 1000 (4byte)	1000	Current variance value of survey position (m)
4	sigma threshold	000 to 255 (3byte)	000 Δ3	Sigma threshold (m) which changes automatically to position-fixed.
5	time	0 to 999999 (6byte)	000000	Current update times of survey position (sec). It is not updated at the time of positioning interruption.
6	time threshold	0 to 604800 (6byte)	028800 Δ3	Time threshold (sec) which changes automatically to position-fixed.
7	TRAIM solution	0 to 2 (1byte)	2	TRAIM solution 0: OK 1: ALARM 2: UNKNOWN, due to a. alarm threshold set too low b. insufficient satellites being tracked
8	TRAIM status	0 to 2 (1byte)	2	TRAIM status 0: detection and isolation possible 1: detection only possible 2: neither possible
9	removed SV	0 to 3 (2byte)	00	number of the removed satellite by TRAIM
10	Receiver status Δ3	10byte	0x00000000	Reserve field

\$PERDCRY,TPS3,2,0003,001,002205,086400,0,0,00,0x00000000*68

Positioning mode: Survey mode (calculation continuously) (2)

Survey sigma: 3 [m]

Survey sigma threshold: 1 [m]

Survey time: 2205 [seconds]

Survey time threshold: 86400 [seconds]

TRAIM solution: OK (0)

TRAIM status: OK (0)

Removed SVs: 0

Receiver status: 0x00000000

Notes:

- This command is output every second.
- \$PERDAPI,CROUT,Y,0*41 stops outputting this command.

CRZ (TPS4) – Output Time Transfer Info per Second (FREQUENCY) $\Delta 3$ Format:

\$PERDCRZ	,	TPS4	,	freq mode	,	Freq status	,	GCLK accuracy	,	e	,	de	,
		1		2		3		4		5		6	

lock cnt	,	lockoff cnt	,	reserve	,	IDtag		GCLK setting 1	,	GCLK setting 2	*hh	<CR>	<LF>
7		8		9		10		11		12			

Num	Contents	Range	Default	Remark
1	TPS4	-	-	Command Name
2	freq mode	1 to 6 (1byte)	1	1: warm up 2: lock 3: hold over 4: free run 5: coarse mode 6: fine mode
3	Freq status	0 or 1 (1byte)	0	0: Not output 1: Output
4	GCLK accuracy	0 or 1 (1byte)	0	0: Not accurate 1: GCLK PPS and GCLK frequency are accurate
5	e	-999999 to +999999 (7byte)	-	Phase delay between LEGACY and GCLK PPS (no dimensional)
6	de	-999999 to +999999 (7byte)	-	Amount of change of phase delay (no dimensional)
7	lock cnt	0 to 999999 (7byte)	-	Duration time of Lock (sec)
8	lockoff cnt	0 to 999999 (7byte)	-	Duration time of holdover/free run (sec)
9	reserve	0x00 to 0xFF (6byte)	-	Reserve field
10	IDtag	(6byte)	-	Product name and last two digits of product version In case of GT-8777 of "4850466003" ➔ 8777 + 03 = 877703 In case of GT-87 of "4850466005" ➔ 8700 + 05 = 870005
11	GCLK setting 1	(4byte)	-	Reserve field
12	GCLK setting 2	(4byte)	-	Reserve field

\$PERDCRZ,TPS4,1,1,0,+000000,+000000,+000000,+000000,000000,000000,0x15,0000*57

Freq mode: warm up

Freq status: output

GCLK accuracy: accurate

Notes:

- This command is output every second.
- \$PERDAPI,CROUT,Z,0*42 stops outputting this command.

CRM – Measurement Data of GPS

Format:

\$PERDCRM	,	time	,	sennum	,	maxsen	,	system	,	svid	,	reserve
		1		2		3		4		5		6

snr	,	adr	,	doppfreq	,	pseudorange	*hh	<CR>	<LF>
7		8		9		10			

Num	Contents	Range	Default	Remark
1	time	0 to 604799	-	GPS time of week
2	sennum	1 to 32	-	Sentence number
3	maxsen	1 to 32	-	Maximum number of sentences
4	system	1	-	GNSS system ID (1=GPS)
5	svid	1 to 99	-	Satellite number
6	reserve	1 to 3	-	Reserve field
7	snr	0 to 55	-	Signal to Noise Ration [dB-Hz]
8	adr	32bit	-	Accumulated Doppler Range [Cycles, LSB=-6]
9	doppfreq	32bit	-	Doppler Frequency [meters/sec, LSB=-12]
10	pseudorange	32bit	-	Pseudorange [meters, LSB=-6]

Example:

```
$PERDCRM,467055,9,10,1,18,2,40,251470,-225117,1630912949*4C
```

Notes:

- This sentence will be output as a set once per second and will contain measurements for all GPS systems.
- To output this sentence, please input "\$PERDAPI,CROUT,M,1*54" when baud rate is 115200bps.

CRN – Navigation Data

Format:

\$PERDCRN	,	system	,	svid	,	subframe data	*hh	<CR>	<LF>
		1		2		3			

Num	Contents	Range	Default	Remark
1	system	1	-	GNSS system ID (1=GPS)
2	svid	1 to 99	-	Satellite number
3	subframe data	10 words (60 strings)	-	Subframe data no parirt included

Example:

```
$PERDCRN,1,7,8B0B349809AC00424A2471C5FF9F27BB10C82EB5884CC987FFA50C0BF2A8*0C
```

Notes:

- For each GPS satellite decoding data, this string is output once every 6 seconds.
- For GPS, the subframe field is a hexadecimal representation of all 10 words of a subframe.
- If a word was not decoded or contained a parity error, the six characters associated with that word will be reported as "-----".
- To output this sentence, please input "\$PERDAPI,CROUT,N,1*57" when baud rate is 115200bps.

SYS – Answer of PVT System

7.3.1 ERSION- Software Version

Format:

\$PERDSYS	,	VERSION	,	device	,	version	,	reserve1	,	reserve2	*hh	<CR>	<LF>
		1		2		3		4		5			

Num	Contents	Range	Default	Remark
1	VERSION	-	-	Command Name
2	device	-	-	Device Name
3	version	-	-	Version number
4	reserve1	-	-	Reserve field
5	reserve2	-	-	Reserve field

Example:

```
$PERDSYS,VERSION,OPUS7_SFLASH_ES2_64P,ENP622A1226410F,QUERY,N/A*1A
```

Notes:

- Character string of the device and version is free format.

GPIO- General Purpose Input/output Format:

\$PERDSYS	,	GPIO	,	state	*hh	<CR>	<LF>
		1		2			

Num	Contents	Range	Default	Remark
1	GPIO	-	-	Command Name
2	state	H or L	-	GPIO state (H:High , L:Low)

Example:

```
$PERDSYS,GPIO,HHHHLLLL*4B
```

Notes:

- This first character represents GPIO 0 and the last character represents GPIO 8.

FIXSESSION- Fix Session Δ 1 Format:

\$PERDSYS	,	FIXSESSION	,	reserve1	[,	reserve2	,	reserve3]	*hh	<CR>	<LF>
		1		2		3		4			

Num	Contents	Range	Default	Remark
1	FIXSESSION	-	-	Command Name
2	reserve1	-	-	reserve field
3	reserve2	-	-	reserve field
4	reserve3	-	-	reserve field

Example:

\$PERDSYS,FIXSESSION,ON,19015,19.015*7C

Notes:

- This string is sent when certain events occur. This is for *eRide* use only.

ANTSEL- Antenna selecting Δ 1 Format:

\$PERDSYS	,	ANTSEL	,	reserve1	,	reserve2	*hh	<CR>	<LF>
		1		2		3			

Num	Contents	Range	Default	Remark
1	ANTSEL	-	-	Command Name
2	reserve1	-	-	reserve field
3	reserve2	-	-	reserve field

Example:

\$PERDSYS,ANTSEL,FORCE1L,1LOW*32

Notes:

- This string is sent when certain events occur. This is for *eRide* use only.

BBRAM - Battery Backup Random Access Memory Δ 1 Format:

\$PERDSYS	,	BBRAM	,	reserve1	[,	reserve2]	*hh	<CR>	<LF>
		1		2		3			

Num	Contents	Range	Default	Remark
1	BBRAM	-	-	Command Name
2	reserve1	-	-	reserve field
3	reserve2	-	-	reserve field

Example:

\$PERDSYS,BBRAM,PASS*15

Notes:

- This string is sent when certain events occur. This is for *eRide* use only.

MSG – Event Driven Message Δ 1 Format:

\$PERDMSG	,	key	[,	string]	*hh	<CR>	<LF>
		1		2			

Num	Contents	Range	Default	Remark
1	key	-	-	Alphanumeric event indicator
2	string	-	-	Description of event

Example:

\$PERDMSG,1A*06

Notes:

- This string is sent when certain events occur. Some strings are for *eRide* use only and contain only an alphanumeric key. Others provide user feedback and contain description of the event.

10 Backup of the Receiver Parameters (for BBRAM) ^{Δ4}

The parameters which this receiver has backed up are shown below.

Chart. Backup of the receiver parameter

CONTENTS	PARAMETER	HOT	WARM	COLD	FACTORY	POWER OFF/ON
Present time	Date & Time	YES	YES	YES	NO	YES
	Millennium	YES	YES	YES	NO	YES
Receiver's present position	Latitude	YES	YES	YES	NO	YES
	Longitude	YES	YES	YES	NO	YES
	Altitude	YES	YES	YES	NO	YES
Receiver's hold position[*1]	Latitude	YES	YES	YES	NO	YES[*3]
	Longitude	YES	YES	YES	NO	YES[*3]
	Altitude	YES	YES	YES	NO	YES[*3]
Ephemeris	Ephemeris data	YES	NO	NO	NO	YES[*2]
Almanac	Almanac data	YES	YES	NO	NO	YES

Chart. Backup of the receiver parameter of command

COMMAND NAME	PARAMETER	HOT	WARM	COLD	FACTORY	POWER OFF/ON
GNSS	GNSS setting	YES	YES	YES	NO	YES
FIXMASK	FIXMASK setting	YES	YES	YES	NO	YES
PPS	PPS setting	YES	YES	YES	NO	YES
TIMEZONE	GMT setting	YES	YES	YES	NO	YES
SURVEY	position mode	YES	YES	YES	NO	YES
	Sigma threshold for survey	YES	YES	YES	NO	YES
	Time threshold for survey	YES	YES	YES	NO	YES
	Current sigma for survey	YES[*3]	YES[*3]	YES[*3]	NO	YES[*3]
	Current time for survey	YES[*3]	YES[*3]	YES[*3]	NO	YES[*3]
FREQ	FREQ setting	YES	YES	YES	NO	YES
CROUT	CROUT setting	YES	YES	YES	NO	YES
DEFLS	Default leap sec	YES	YES	YES	NO	YES

TIMEALIGN	Time alignment	YES	YES	YES	NO	YES
FLASHBACKUP	Backup in flash	YES	YES	YES	YES	YES

Chart. Backup of the configure parameter of command

COMMAND NAME	PARAMETER	HOT	WARM	COLD	FACTORY	POWER OFF/ON
UART1	Baud rate of UART1	YES	YES	YES	YES	NO
NMEAOUT	NMEA output interval	YES	YES	YES	YES	NO

[*1] The position calculated by position survey mode or input by \$PERDAPI,SURVEY,3. [*2] There is a time limitation (4 hours).

[*3] CSS (continues survey) mode or TO (time only) mode only

LIMITED HARDWARE WARRANTY

Novus Power Products (hereinafter Novus) warrants its products to the original end user ("original purchaser") and warranty is not transferrable. Novus guarantees that the NOVUS hardware products that you have purchased from NOVUS are free from defects in materials or workmanship under normal use during the LIMITED WARRANTY PERIOD. The LIMITED WARRANTY PERIOD starts on the date of shipment and for the period of 1 (one) year to be free from defects caused by faulty materials or poor workmanship, provided:

(a) NOVUS is notified in writing by Buyer of such defect prior to the expiration of the warranty period, and
(b) after receiving return authorization –RMA– from NOVUS, the defective item is returned with transportation prepaid to NOVUS, Independence, Missouri, with transportation charges prepaid by Buyer ... see RMA policy in Terms and conditions, and

(c) NOVUS's examination of such unit shall disclose to its satisfaction that such defect(s) exist and have not been caused by misuse, neglect, improper installation, improper storage, unauthorized modifications, inadequate maintenance, operation outside the environmental specifications for the product, repair alteration, or accident. NOVUS assumes no risk or liability for results of the use of products purchased from it, including but without limiting the generality of the foregoing: (1) the use in combination with any electrical or electronic components, circuits, systems, assemblies or any other materials or substances; (2) unsuitability of any product for use in any circuit or assembly. Removal or tampering with tamper-proof label on merchandise will void warranty coverage unless with the written authorization from NOVUS
(d) an evaluation fee will be charged to Buyer to cover inspection and testing costs for any item returned by Buyer under this paragraph which is found to be within specifications and/or otherwise not the responsibility of NOVUS under the terms and conditions of this paragraph or any other part of this Agreement.

Your dated sales or delivery receipt is your proof of the purchase date. You may be required to provide proof of purchase as a condition of receiving warranty service. You are entitled to hardware warranty service according to the terms and conditions of this document if a repair to your NOVUS product is required during the limited warranty period. Our obligation at NOVUS is limited to repair or replace products which prove to be defective.

Should Novus be unable to repair or replace the product within a reasonable amount of time, the customer's alternate remedy shall be a refund of the purchase price upon return of the product to Novus. The liability of NOVUS under this warranty is limited to replacing, repairing or issuing a credit, at its option, for any such item returned by Buyer under the terms of this warranty.

EXCLUSIONS: The above warranty shall not apply to defects resulting from improper or inadequate maintenance by the customer, customer-supplied software or interfacing, unauthorized modification or misuse, operation outside of the environmental specifications for the product or improper site preparation and maintenance (if applicable). For probes, cables, antennas and accessories, the warranty period is 90 (ninety) days.

PRODUCT SPECIFICATIONS: Published specifications whether contained herein or in any other materials or documents distributed to Buyer by Novus do not become final or binding on NOVUS until approved by NOVUS. NOVUS expressly reserves the right to change or modify specifications at any time without prior notice.

WARRANTY LIMITATIONS: NOVUS MAKES NO OTHER WARRANTY, EITHER EXPRESSED OR IMPLIED, WITH RESPECT TO THIS PRODUCT. NOVUS SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

IN ALL CIRCUMSTANCES NOVUS' MAXIMUM LIABILITY IS LIMITED TO THE PURCHASE PRICE OF THE PRODUCTS SOLD. NOVUS SHALL NOT, UNDER ANY CIRCUMSTANCES BE LIABLE UPON A CLAIM OR ACTION IN CONTRACT, TORT, INDEMNITY OR CONTRIBUTION OR OTHER CLAIMS RELATING TO THE PRODUCTS IT SELLS WHICH EXCEEDS THIS LIABILITY LIMIT. NOVUS SHALL NOT BE LIABLE FOR THIRD PARTY CLAIMS FOR DAMAGES AGAINST THE CUSTOMER, OR FOR MALFUNCTION, DELAYS, INTERRUPTION OF SERVICE, LOSS OF BUSINESS, LOSS OR DAMAGE TO EXEMPLARY DAMAGES, WHETHER OR NOT NOVUS HAS BEEN MADE AWARE OF THE POSSIBILITY OF SUCH CLAIMS OR DAMAGES.

LIMITATION OF REMEDIES: REGARDLESS OF WHETHER ANY REMEDY SET FORTH HEREIN FAILS OF ITS ESSENTIAL PURPOSE, IN NO EVENT WILL NOVUS BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INDIRECT OR SIMILAR DAMAGES, INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF DATA OR BUSINESS INFORMATION (OR OTHER PECUNIARY LOSS) ARISING OUT OF THE USE



Users manual	Appendix A
Revision #:	B
Date:	7-13-15

OF OR INABILITY TO USE THE HARDWARE SUPPLIED THEREWITH EVEN IF NOVUS OR ANYONE ELSE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR FOR ANY CLAIM BY ANY OTHER PARTY. EXCLUDED DAMAGES SHALL INCLUDE, BUT ARE NOT LIMITED TO: COSTS OF REMOVAL AND INSTALLATION, LOSSES SUSTAINED AS THE RESULT OF INJURY TO ANY PERSON, OR DAMAGE TO PROPERTY.

EXCLUSIVE REMEDIES: THE REMEDIES PROVIDED HEREIN ARE THE CUSTOMERS' SOLE AND EXCLUSIVE REMEDIES. IN NO EVENT SHALL NOVUS BE LIABLE FOR ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, WHETHER BASED ON CONTRACT, TORT, OR ANY OTHER LEGAL THEORY.

User Manual**\$GPNVS****Appendix C: \$GPNVS Status String Definitions**

All information provide herein is the proprietary property of Novus Power Products L.L.C. The information included may be reproduced without the permission of Novus Power Products L.L.C. with out prior approval for purpose of operating the equipment.

Contents

1.0 The \$GPNVS Serial Status String	3
1.1 Status String (\$GPNVS,1) Fault Bytes	4
1.2 Status String (\$GPNVS,2) Channel Values 1-8	5
1.3 Status String (\$GPNVS,3) Power Supply Values.....	6
1.4 Status String (\$GPNVS,4) Channel Values 9-16	7
1.5 Status String (\$GPNVS,5) Sensors	8
1.6 Status String (\$GPNVS,6) Status Bytes	9
1.6.1 Status String (\$GPNVS,6) Status Bytes; Standard	9
1.6.2 Status String (\$GPNVS,6) Status Bytes; Rubidium	10
1.7 Status String (\$GPNVS,7) Status Bytes	11
1.8 Event String (\$GPNVS,8) Event Status.....	12
1.9 Status String (\$GPNVS,9) Frequency Measurement.....	13
1.9.1 Standard Frequency Measurement String.....	13
1.9.2 NR6720-HS Frequency Measurement String	14
1.10 PPS Alignment String (\$GPNVS,10) PPS Status	15
1.12 PPS Alignment String (\$GPNVS,9) PPS Status	16
1.11 Response String (\$GPNVS,R)	17
1.12 Discipline Selection String (\$GPNVS,13).....	18
2.0 Combined NMEA/Status RS232	19
2.1 Status String (\$GPNVS,1) Fault Bytes	19
2.2 Status String (\$GPNVS,2) Channel Values.....	20
2.3 Status String (\$GPNVS,3) Power Supply Values.....	21
3.0 Status Byte Key.....	22

1.0 The \$GPNVS Serial Status String

Novus products provide, in many cases, serial data output from a standard GNSS receiver matching the NMEA 0183 protocol. This is usually a direct connection to the receiver.

In addition to NMEA, Novus Products which provide an additional RS232 serial port for status monitoring, will be set up to meet the following protocols. These are designed to be standardized across different products, and easy to port and use via serial-to-ethernet connections.

Many products will have some, but not all, of the following strings, if configured for the optional status RS232.

The following products comply with this document:

1. ND0115
2. NR2310-OG
3. NR2315
4. NR2110-O
5. NR2110-OG (Separate Status Port)
6. NR2110-OG (Combined NMEA/Status Port)
7. NR6720
8. NR2304

Note: The NR2110-OG with combined NMEA and Status Port complies with section 2.0 “Combined NMEA/Status RS232”

1.1 Status String (\$GPNVS,1) Fault Bytes

\$GPNVS	1	hhmmss	mmddyy	A	A	nn	nn	0x0000	0x00	0x00	n	n	*	XX
1	2	3	4	5	6	7	8	9	10	11	12	13		14

#	Description	Range
1.	Identifier	\$GPNVS
2.	String ID	1
3.	Time (UTC)	hhmmss
4.	Date	mmddyy
5.	GPS 1 Lock (Valid)	“A” = Valid, “V” = Not Valid, “N” = N/A
6.	GPS 2 Lock (Valid)	“A” = Valid, “V” = Not Valid, “N” = N/A
7.	# of Sats in View (1)	Greater of GPS or GNSS count, “N” = N/A
8.	# of Sats in View (2)	Greater of GPS or GNSS count, “N” = N/A
9.	Channel Fault Byte	0x0000 to 0xFFFF (Hex OR'd value)
10.	Power Supply Fault Byte	0x00 to 0xFF (Hex OR'd value)
11.	Error Message Byte	0x00 to 0xFF (Hex OR'd value)
12.	Antenna 1	“0” = Ok, “1” = Error, “N” = N/A
13.	Antenna 2	“0” = Ok, “1” = Error, “N” = N/A
14.	NMEA Checksum	*XX (xor'd value of bytes between \$ and *)

Example:

\$GPNVS,1,233518,092516,A,A,10,11,0x0000,0x00,0x00,0,0*23

1.2 Status String (\$GPNVS,2) Channel Values 1-8

\$GPNVS	2	hhmmss	ddmmyy	n.nn	n.nn	n.nn	n.nn	n.nn	n.nn	n.nn	n.nn	*	XX
1	2	3	4	5	6	7	8	9	10	11	12		13

#	Description	Range
1.	Identifier	\$GPNVS
2.	String ID	2
3.	Time (UTC)	hhmmss
4.	Date	mmdyy
5.	Channel 1 Vrms	0.00 to 3.30 [V]
6.	Channel 2 Vrms	0.00 to 3.30 [V]
7.	Channel 3 Vrms	0.00 to 3.30 [V]
8.	Channel 4 Vrms	0.00 to 3.30 [V]
9.	Channel 5 Vrms	0.00 to 3.30 [V]
10.	Channel 6 Vrms	0.00 to 3.30 [V]
11.	Channel 7 Vrms	0.00 to 3.30 [V]
12.	Channel 8 Vrms	0.00 to 3.30 [V]
13.	NMEA Checksum	*XX (xor'd value of bytes between \$ and *)

Example:

\$GPNVS,2,233518,092516,2.56,2.48,2.51,2.60,2.44,2.53, 2.51,2.60*6C

Note: For units with fewer than the number of channels listed, a null value will be present.

1.3 Status String (\$GPNVS,3) Power Supply Values

\$GPNVS	3	hhmmss	ddmmyy	n.nn	n.nn	n.nn	n.nn	n.nn	n.nn	n.nn	n.nn	n	nn	*	XX
1	2	3	4	5	6	7	8	9	10	11	12	13	14		15

#	Description	Range
1.	Identifier	\$GPNVS
2.	String ID	3
3.	Time (UTC)	hhmmss
4.	Date	mmdyy
5.	Power Supply 1	-30.0 to 30.0 [V]
6.	Power Supply 2	-30.0 to 30.0 [V]
7.	Power Supply 3	-30.0 to 30.0 [V]
8.	Power Supply 4	-30.0 to 30.0 [V]
9.	Power Supply 5	-30.0 to 30.0 [V]
10.	Power Supply 6	-30.0 to 30.0 [V]
11.	Power Supply 7	-30.0 to 30.0 [V]
12.	Power Supply 8	-30.0 to 30.0 [V]
13.	Built in Test (BIT)	0 = Ok, 1 = Fail
14.	Temperature (C)	-40 to 99
15.	NMEA Checksum	*XX (xor'd value of bytes between \$ and *)

Example:

\$GPNVS,3,233518,092516,-7.84,7.93,-11.8,12.1,0.00,0.00,0.00,1.92,0,26*62

Note: Depending on configuration, Power Supply values will be defined differently, and some Power Supply values may not be present.

1.4 Status String (\$GPNVS,4) Channel Values 9-16

\$GPNVS	4	hhmmss	ddmmyy	n.nn	n.nn	n.nn	n.nn	n.nn	n.nn	n.nn	n.nn	*	XX
1	2	3	4	5	6	7	8	9	10	11	12		13

#	Description	Range
1.	Identifier	\$GPNVS
2.	String ID	4
3.	Time (UTC)	hhmmss
4.	Date	mmdyy
5.	Channel 9 Vrms	0.00 to 3.30 [V]
6.	Channel 10 Vrms	0.00 to 3.30 [V]
7.	Channel 11 Vrms	0.00 to 3.30 [V]
8.	Channel 12 Vrms	0.00 to 3.30 [V]
9.	Channel 13 Vrms	0.00 to 3.30 [V]
10.	Channel 14 Vrms	0.00 to 3.30 [V]
11.	Channel 15 Vrms	0.00 to 3.30 [V]
12.	Channel 16 Vrms	0.00 to 3.30 [V]
13.	NMEA Checksum	*XX (xor'd value of bytes between \$ and *)

Example:

\$GPNVS,4,233518,092516,2.56,2.48,2.51,2.60,2.44,2.53,2.51,2.60*6A

Note: For units with fewer than the number of channels listed, a null value will be present.

1.5 Status String (\$GPNVS,5) Sensors

\$GPNVS	5	hhmmss	ddmmyy	nnn	nn	±nn	*	XX
1	2	3	4	5	6	7		8

#	Description	Range
1.	Identifier	\$GPNVS
2.	String ID	5
3.	Time (UTC)	hhmmss
4.	Date	mmdyy
5.	Potentiometer	Hex Value 000 to FFF
6.	Fan PWM %	0 to 90
7.	Temperature	-40 to 99 [C]
8.	NMEA Checksum	*XX (xor'd value of bytes between \$ and *)

Example:

\$GPNVS,5,233518,092516,45,00,25*70

1.6 Status String (\$GPNVS,6) Status Bytes

There are two different Status Strings; one for everything except the NR2304 and one for the NR2304.

1.6.1 Status String (\$GPNVS,6) Status Bytes; Standard

\$GPNVS	6	0	A	0	0x0000	0x00	0x00	0x00	0	0x0000	0x0000	0x0000	*	XX
1	2	3	4	5	6	7	8	9	10	11	12	13		14

#	Description	Range
1.	Identifier	\$GPNVS
2.	String ID	6
3.	Active PCB Assembly	0 or 1
4.	GNSS Lock	A = Locked, V = Unlocked
5.	Input Error	0 = Ok, 1 = A Error, 2 = B error
6.	Channel Status Word	0x0000 to 0xFFFF
7.	Primary PS Status	0x00 to 0xFF
8.	Secondary PS Status	0x00 to 0xFF
9.	Active PCB Status	0x00 to 0xFF
10.	Checksum Status	00 to 999
11.	Channel Fault Bin	0x0000 to 0xFFFF
12.	Primary PCB Amp Status	0x0000 to 0xFFFF
13.	Backup PCB Amp Status	0x0000 to 0xFFFF
14.	NMEA Checksum	*XX (xor'd value of bytes between \$ and *)

Example:

\$GPNVS,6,0,A,0,0x0000,0x40,0x40,0x00,00,0x0000,0x0000,0x0000*63

See Status Byte Table for details.

1.6.2 Status String (\$GPNVS,6) Status Bytes; Rubidium

\$GPNVS	6	nnn	0x0000	nnn	0/1	*	XX
1	2	3	4	5	6	7	

#	Description	Range
1.	Identifier	\$GPNVS
2.	String ID	6
3.	Heat Sink Temperature	0-255
4.	Heater Current Voltage	0x0000-0x0136
5.	Measured Voltage in Heater	0-255
6.	Rb Locked	0 = Unlocked 1= Locked
7.	NMEA Checksum	*XX (xor'd value of bytes between \$ and *)

Example:

\$GPNVS,9,136,0x002A,90,1*7E

1.7 Status String (\$GPNVS,7) Status Bytes

\$GPNVS	7	nnnnnn	nnnnnn	A	nn	0x00	0	0	0	nnnnnn	n.nn	n.nn	*	XX
1	2	3	4	5	6	7	8	9	10	11	12	13		14

#	Description	Range
1.	Identifier	\$GPNVS
2.	String ID	7
3.	Time	hhmmss
4.	Date	mmddyy
5.	GPS Lock	"A" = Valid, "V" = Not Valid
6.	# of Sats in View (1)	Greater of GPS or GNSS count, "N" = N/A
7.	Error Byte	0x00 to 0xFF
8.	Freq Diff	±999 (last count, clock cycles)
9.	PPS Diff	±999 (last count, clock cycles)
10.	Freq Correction Slice	±999 (DAC bits, per second)
11.	DAC Value	Integer Representation, $n \times 1/(2^{20})$
12.	Power Supply	Vdc
13.	Power Supply	Vdc
14.	NMEA Checksum	*XX (xor'd value of bytes between \$ and *)

Example:

\$GPNVS,7,161505,081617,A,12,0x00,-1,-2,0,505610,+5.05,-4.66*58

1.8 Event String (\$GPNVS,8) Event Status

\$GPNVS	8	0	0	0	0	0	0	0	nnnnnn	0	*	XX
1	2	3	4	5	6	7	8	9	10	11		12

#	Description	Range
1.	Identifier	\$GPNVS
2.	String ID	8
3.	Discipline Counter	0 = Off, 1 = Disciplined to Synthetic PPS
4.	User Enabled	0 = Off, 1 = On
5.	Event Enabled (System)	0 = Events Disabled, 1 = Events Enabled
6.	GPS Lock Achieved	0 = No Lock, 2 = Locked or previously locked
7.	Event Index	0-512, Current count of events in RAM
8.	Event Errors (RAM)	0
9.	Event Index	0-512, Current count of events in Flash
10.	Event Errors (Flash)	0
11.	Event Time Alignmet	2 = LS applied, 1 = GPS, 0 = RTC
12.	Estimated Accuracy	0-999999 [ns]
13.	Edge Detect Direction	0 = Falling Edge, 1 = Rising Edge
14.	NMEA Checksum	*XX (xor'd value of bytes between \$ and *)

Example:

\$GPNVS,8,1,1,1,2,0,0,2,000005,0*60

1.9 Status String (\$GPNVS,9) Frequency Measurement

The frequency measurement string has two versions, one standard version, and one for the NR6720.

1.9.1 Standard Frequency Measurement String

\$GPNVS	9	hhmmss	ddmmyy	(n)nnnnnnn.nnn	nnn	(-)nn	*	XX
1	2	3	4	5	6	7		8

#	Description	Range
1.	Identifier	\$GPNVS
2.	String ID	9
3.	Time (UTC)	hhmmss
4.	Date	mmddyy
5.	Measured Frequency	9999900.000 to 10000100.000
6.	Frequency Alert Range	0 – 240 (units of 0.0083 Hz)
7.	Temperature	-40 to 99 [C]
8.	NMEA Checksum	*XX (xor'd value of bytes between \$ and *)

Example:

\$GPNVS,9,233518,092516,10000000.003,240,25*70

1.9.2 NR6720-HS Frequency Measurement String

\$GPNVS	9	nnnnnnnn.nnn	n.nnnnnn	nnnnnnnnn.nn	0	±n.nn	±n.nn	*	XX
1	2	3	4	5	6	7	8		9

#	Description	Range
1.	Identifier	\$GPNVS
2.	String ID	9
3.	Frequency (Loop Period)	10000000.000
4.	DAC Voltage (Double)	2.000000
5.	Frequency (per second)	10000000.0
6.	Loop Period	0-99
7.	Antenna Current Mon	0.00 to 3.30V
8.	Sine Output RMS	0.00 to 3.30V
9.	NMEA Checksum	*XX (xor'd value of bytes between \$ and *)

Example:

\$GPNVS,9,+10000000.003,+1.97493,+10000000.0,15,+1.03,+1.30*4A

1.10 PPS Alignment String (\$GPNVS,10) PPS Status

\$GPNVS	10	0	0	0	±n	±n	n	n	n.n	n	n	n	0	±n	n.n	n	*	XX
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	

#	Description	Range
1.	Identifier	\$GPNVS
2.	String ID	10
3.	PPS Stability Enabled	0 = Off, 1 = On
4.	PPS Disciplining to GPS	0 = Off, 1 = Actively Synchronized
5.	PPS Output Type	0 = Synthetic PPS, 1 = GPS PPS
6.	PPS Difference	±250 [ns]
7.	PPS Avg Difference	±250 [ns]
8.	PPS Avg Count	1-20
9.	PPS Synch Threshold	1-250
10.	PPS pull Cal Factor	0.1 to 10.0
11.	PPS active Time Cal Factor	0 to 9
12.	Frequency Variance	0-9999 (clock cycles per Loop period)
13.	Frequency Var Threshold	0-100 (clock cycles per Loop period)
14.	PPS Stable Mode Post-Warm up	0 = Off, 1 = On
15.	PPS Slope Indicator	±250 (clock cycles per second)
16.	PPS Slope Cal Factor	0.1 to 10.0
17.	PPS Slope Distance	14 to 60 (seconds)
18.	NMEA Checksum	*XX (xor'd value of bytes between \$ and *)

Example:

\$GPNVS,10,1,0,0,+0,+0,2,100,0.5,3,2,10,1,0,1.0*46

1.12 PPS Alignment String (\$GPNVS,9) PPS Status

\$GPNVS	9	nnn	0x0000	nnn	0/1	*	XX
1	2	3	4	5	6	7	

#	Description	Range
8.	Identifier	\$GPNVS
9.	String ID	9
10.	Heat Sink Temperature	0-255
11.	Heater Current Voltage	0x0000-0x0136
12.	Measured Voltage in Heater	0-255
13.	Rb Locked	0 = Unlocked 1= Locked
14.	NMEA Checksum	*XX (xor'd value of bytes between \$ and *)

Example:

\$GPNVS,9,136,0x002A,90,1*7E

1.11 Response String (\$GPNVS,R)

\$GPNVS	R	n	<response>	*	XX
1	2	3	4	5	

#	Description	Range
1.	Identifier	\$GPNVS
2.	Response ID	R
3.	Command Success	1 = Success, 0 = Fail
4.	Response	<see example responses>
5.	NMEA Checksum	*XX (xor'd value of bytes between \$ and *)

Example:

\$GPNVS,R,SET01=1.00*6F

1.12 Discipline Selection String (\$GPNVS,13)

\$GPNVS,	13,	n,	n,	n,	n,	n,	,	,	*	XX
1	2	3	4	5	6	7	8	9		10

#	Description	Range
1.	Identifier	\$GPNVS
2.	String ID	13
3.	Priority Discipline Source	0 = GNSS, 1 = 10MHz input, 2 = Optical input
4.	Current Discipline Source	0 = GNSS, 1 = 10MHz, 2 = Optical, 3 = Holdover
5.	GNSS Lock	0 to 3, 0 = Unlocked, 3 = Fully Locked
6.	RF Present	0 = No RF source, 1 = RF Source found
7.	Opto Present	0 = No Optical source, 1 = Optical Source Found
8.	Loop Lock	1 = Lock, 0 = Loop acquiring lock
9.	Reserved	
10.	NMEA Checksum	*XX (xor'd value of bytes between \$ and *)

Example:

\$GPNVS,13,0,0,3,0,0,1,*5C

2.0 Combined NMEA/Status RS232

NR2110-OG Combined NMEA?Status Port

2.1 Status String (\$GPNVS,1) Fault Bytes

\$GPNVS	1	hhmmss	mmddyy	A	nn	0x00	0x00	0x00	*	XX
1	2	3	4	5	6	7	8	9		10

#	Description	Range
15.	Identifier	\$GPNVS
16.	String ID	1
17.	Time (UTC)	hhmmss
18.	Date	mmddyy
19.	GPS Lock (Valid)	"A" = Valid, "V" = Not Valid
20.	# of Sats in View	Greater of GPS or GNSS count
21.	Channel Fault Byte	0x00 to 0x3F (Hex OR'd value)
22.	Power Supply Fault Byte	0x00 to 0x1F (Hex OR'd value)
23.	Error Message Byte	0x00 to 0x0F (Hex OR'd value)
24.	NMEA Checksum	*XX (xor'd value of bytes between \$ and *)

Example:

\$GPNVS,1,233518,092516,A,10,0x00,0x00,0x00*62

Time: 23:35:18; Sep. 25, 2016, GPS locked; 10 Satellites in view; No channel faults; No power supply faults; No error messages.

2.2 Status String (\$GPNVS,2) Channel Values

\$GPNVS	1	hhmmss	mmddyy	n.nn	n.nn	n.nn	n.nn	n.nn	n.nn	*	XX
	1	2	3	4	5	6	7	8	9	10	11

#	Description	Range
14.	Identifier	\$GPNVS
15.	String ID	2
16.	Time (UTC)	hhmmss
17.	Date	mmddyy
18.	Channel 1 Vrms	0.00 to 6.60 [V]
19.	Channel 2 Vrms	0.00 to 6.60 [V]
20.	Channel 3 Vrms	0.00 to 6.60 [V]
21.	Channel 4 Vrms	0.00 to 6.60 [V]
22.	Channel 5 Vrms	0.00 to 6.60 [V]
23.	Channel 6 Vrms	0.00 to 6.60 [V]
24.	NMEA Checksum	*XX (xor'd value of bytes between \$ and *)

Example:

\$GPNVS,2,233518,092516,0.99,1.01,1.06,0.97,1.52,1.54*4E

2.3 Status String (\$GPNVS,3) Power Supply Values

\$GPNVS	3	hhmmss	mmddyy	n.nn	n.nn	n.nn	n.nn	n.nn	*	XX
1	2	3	4	5	6	7	8	9		10

#	Description	Range
15.	Identifier	\$GPNVS
16.	String ID	2
17.	Time (UTC)	hhmmss
18.	Date	mmddyy
19.	-5Vdc Power Supply(opt)	-30.0 to 30.0 [V]
20.	+5Vdc Power Supply	-30.0 to 30.0 [V]
21.	10k Ω Thermistor(opt)	0.00 to 3.30 [V]
22.	+5Vdc Power Supply(opt)	-30.0 to 30.0 [V]
23.	OCXO Control Voltage	0.00 to 3.30 [V]
24.	NMEA Checksum	*XX (xor'd value of bytes between \$ and *)

Example:

\$GPNVS,3,233518,092516,-4.84,4.93,1.45,4.90,2.12*42

3.0 Status Byte Key

Channel Status Byte	Hex Value (OR'd)	Channel ID	Channel Status Word
	0x1<<0	Channel 1 Fault	General Channel Fault
	0x1<<1	Channel 2 Fault	
	0x1<<2	Channel 3 Fault	
	0x1<<3	Channel 4 Fault	
	0x1<<4	Channel 5 Fault	
	0x1<<5	Channel 6 Fault	
	0x1<<6	Channel 7 Fault	
	0x1<<7	Channel 8 Fault	
	0x1<<8	Channel 9 Fault	
	0x1<<9	Channel 10 Fault	
	0x1<<10	Channel 11 Fault	
	0x1<<11	Channel 12 Fault	
	0x1<<12	Channel 13 Fault	
	0x1<<13	Channel 14 Fault	
	0x1<<14	Channel 15 Fault	

Channel Fault Bin	Hex Value (OR'd)	Channel ID	Channel Fault Bin
	0x1<<0	Channel 1 Fault	<p>External Fault: The ND0100 has completed an internal amplifier gain test and both primary and backup assemblies are functional. The fault is external to the ND0100 (cabling, short, etc)</p> <p>Amp Gain Test for Alert is enabled with \$AMP=1 command via RS232</p>
	0x1<<1	Channel 2 Fault	
	0x1<<2	Channel 3 Fault	
	0x1<<3	Channel 4 Fault	
	0x1<<4	Channel 5 Fault	
	0x1<<5	Channel 6 Fault	
	0x1<<6	Channel 7 Fault	
	0x1<<7	Channel 8 Fault	
	0x1<<8	Channel 9 Fault	
	0x1<<9	Channel 10 Fault	
	0x1<<10	Channel 11 Fault	
	0x1<<11	Channel 12 Fault	
	0x1<<12	Channel 13 Fault	
	0x1<<13	Channel 14 Fault	
	0x1<<14	Channel 15 Fault	

Primary PCB Amp Status	Hex Value (OR'd)	Channel ID	Primary PCB Amp Status
	0x1<<0	Channel 1 Fault	<p>Internal Fault Primary Assembly: The channel has failed an internal gain test on the primary PCB assembly, and the channel is not functional on the primary board.</p> <p>Amp Gain Test for Alert is enabled with \$AMP=1 command via RS232</p>
	0x1<<1	Channel 2 Fault	
	0x1<<2	Channel 3 Fault	
	0x1<<3	Channel 4 Fault	
	0x1<<4	Channel 5 Fault	
	0x1<<5	Channel 6 Fault	
	0x1<<6	Channel 7 Fault	
	0x1<<7	Channel 8 Fault	
	0x1<<8	Channel 9 Fault	
	0x1<<9	Channel 10 Fault	
	0x1<<10	Channel 11 Fault	
	0x1<<11	Channel 12 Fault	
	0x1<<12	Channel 13 Fault	
	0x1<<13	Channel 14 Fault	
	0x1<<14	Channel 15 Fault	

Backup PCB Amp Status	Hex Value (OR'd)	Channel ID	Backup PCB Amp Status
	0x1<<0	Channel 1 Fault	<p>Internal Fault Backup Assembly: The channel has failed an internal gain test on the backup PCB assembly, and the channel is not functional on the secondary board.</p> <p>Amp Gain Test for Alert is enabled with \$AMP=1 command via RS232</p>
	0x1<<1	Channel 2 Fault	
	0x1<<2	Channel 3 Fault	
	0x1<<3	Channel 4 Fault	
	0x1<<4	Channel 5 Fault	
	0x1<<5	Channel 6 Fault	
	0x1<<6	Channel 7 Fault	
	0x1<<7	Channel 8 Fault	
	0x1<<8	Channel 9 Fault	
	0x1<<9	Channel 10 Fault	
	0x1<<10	Channel 11 Fault	
	0x1<<11	Channel 12 Fault	
	0x1<<12	Channel 13 Fault	
	0x1<<13	Channel 14 Fault	
	0x1<<14	Channel 15 Fault	

Active Board Status	Hex Value (OR'd)	Status Message
	0x1<<0	Flash Read Boot Error (Deprecated)
	0x1<<1	Potentiometer Read/Set Fail
	0x1<<2	Reserved
	0x1<<3	Reserved
	0x1<<4	PCB Assembly Input A/B Select Fail
	0x1<<5	Reserved
	0x1<<6	Reserved
	0x1<<7	Reserved

Primary and Secondary Power Supply Status	Hex Value (OR'd)	Status Message
	0x1<<0	PS 1 Fault
	0x1<<1	PS 2 Fault
	0x1<<2	PS 3 Fault
	0x1<<3	PS 4 Fault
	0x1<<4	PS 5 Fault
	0x1<<5	PS 6 Fault
	0x1<<6	PS 7 Fault
	0x1<<7	PS 8 Fault

Error Status	Hex Value (OR'd)	Status Message
	0x1<<0	FLASH_NOT_FOUND
	0x1<<1	FLASH_NOT_SAVED
	0x1<<2	LOOP_VOLT_ERROR
	0x1<<3	ANTENNA_VOLT_ERROR
	0x1<<4	GPS_FAILURE
	0x1<<5	POTENTIOMETER_ERROR
	0x1<<6	RAM_MEMORY_ERROR
	0x1<<7	Reserved